Brookstone®

TV Pillow Remote

GET COMFY–AND CONTROL UP TO SIX DEVICES

TABLE OF CONTENTS

Warnings and Cautions 2
Location of Controls 4
Battery Compartment 5
Remote Programming 6
Code Reading Mode 9
Menu Mode 10
Operating the Remote 11
Care and Maintenance 12
Warranty 13

BATTERY PRECAUTIONS

- Dispose of old batteries properly. Do not dispose of old batteries in a fire.
- Do not leave batteries where a young child or pet could play with or swallow them. If the batteries are swallowed, contact a physician immediately.
- Batteries may explode if mistreated. Do not attempt to recharge or disassemble the batteries.
- Use only fresh batteries of required size and type. Do not mix old and new batteries, different types of batteries, or rechargeable batteries of different capacities.

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a Class B Digital Device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the distance between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This equipment may not cause harmful interference.
2. This equipment must accept any interference received, including interference that may cause undesired operation.

Modifications not authorized by the manufacturer may void the user's authority to operate this device.

LOCATION OF PARTS AND CONTROLS

1. Power
2. Volume +/Volume –
3. Number Panel
4. Channel +/Channel –
5. Input TV/VCR
6. Menu
7. Fast Forward
8. Activate
9. Go Back
10. Pause
11. Play
12. Stop
13. Record
14. Audio
15. Rewind
16. Cable
17. OK
18. DVD
19. Satellite
20. VCR
21. TV
22. Mute
23. LED
24. Battery Compartment (bottom edge)
25. Infrared Sensor (top edge)



BATTERY COMPARTMENT

1. Unzip the pillow and pull out the BATTERY COMPARTMENT. Open the BATTERY COMPARTMENT by sliding the cover with the thumb tab (see below).
2. Insert 2 AAA batteries according to the polarity indicators inside the compartment.
3. Close the BATTERY COMPARTMENT by sliding the battery compartment cover closed securely.
4. Slide the On/Off switch on the BATTERY COMPARTMENT to on.
5. Tuck the BATTERY COMPARTMENT back into the pillow and zip it closed.



Note: If the remote will not be used for an extended period of time, slide the On/Off switch on the BATTERY COMPARTMENT to off.

REMOTE PROGRAMMING

There are three different methods to program your remote to all of your devices: Manual Search Mode, Quick Search Mode and Auto Search Mode.

MANUAL SEARCH MODE

To program your remote under Manual Search Mode, first look up the four-digit code for your device in the included Code Book. There may be several codes listed for your brand. Once you've found your device in the list, follow steps below:

1. Manually turn on the device you wish to program.
2. Press and hold the button for the device (TV/VCR/SAT/DVD/CABLE or AUD) until the LED turns ON.
3. Enter the 4-digit code by pressing the correct numbers on the cushion. The LED will flash once with each digit pressed.
4. The LED will flash three times and then turn OFF if the code is valid. If the LED turns OFF without flashing, it indicates that the 4-digit code is incorrect; you need to repeat all of the previous steps.

You can check if the code matches the device by attempting to use the remote to perform all functions on your device. For example, playing or pausing the device or changing the channel. If the device does not respond appropriately, the code is not correct, and you need to repeat the process with a different code that corresponds with the device's brand.

Note: During the setting, if you press any buttons except the Number buttons, the LED will turn OFF and exit the MANUAL SEARCH MODE, without saving the current settings.

If your code is not available in the Code Book, you can find out your device's code by programming in QUICK SEARCH MODE or AUTO SEARCH MODE, please keep it for your reference in the future.

QUICK SEARCH MODE

To program your remote under Quick Search Mode, you can test and assign device codes to program the remote. Before you begin, read the entire process for programming this remote.

1. Manually turn on the device to which you are programming the remote control.
2. Press and hold the device button (TV/VCR/SAT/DVD/CABLE or AUD) until the LED turns ON.
3. Press the CH+ (search codes up) or CH- (search codes down) button to test if the code matches the device. Each time you press CH+ or CH-, your device is receiving a new code. When the right code is found, the device will turn OFF.
4. Press the OK button to save. The Remote's LED will flash three times and then turn OFF. The remote will then exit the QUICK SEARCH MODE.

Note: (a) If no button is pressed, the remote will automatically exit the QUICK SEARCH MODE after 30 seconds. It will also exit if any key except the CH +, CH-, OK or POWER button is pressed. (b) To check if the code matches the device, try to use the remote with different functions.

Please be patient. The remote is searching through all of the codes and you may need to press CH+ or CH- many times to find the correct code.

AUTO SEARCH MODE

To program your remote in Auto Search Mode, please do as follows:

1. Manually turn on the device to which you are programming the remote control.
2. Press and hold the device button (TV/VCR/SAT/DVD/CABLE or AUD) until the LED turns ON.
3. Press the POWER button, the LED will begin to flash fast, indicating the remote is entering the AUTO SEARCH MODE.
4. When the correct code is found, the LED will flash once, and both the Remote's LED and the device itself will turn OFF.
5. Press the OK button to save. The LED will flash three times and then turn OFF. The remote will then exit the AUTO SEARCH MODE.

Note: (a) The remote will exit if any button except CH +, CH-, OK or POWER button is pressed. (b) In the AUTO SEARCH MODE, it can only search the codes in one direction. (c)To check if the code matches the device, try to program the remote with different operations.

CODE-READING MODE

You can test your chosen codes with operations as follows:

1. Press and hold the button for the device (TV/VCR/SAT/DVD/CABLE or AUD) until the LED turns ON.
2. Press the MUTE button, the LED will flash three times then pause for three seconds to enter the code-reading mode.
3. The LED will flash according to the number and pause with an interval of 1.5 seconds between each number to tell you the code.

For example, when it enters the code-reading mode for code 0028:

- The LED will flash 10 times (0) then pause for 1.5 seconds;
- the LED will flash 10 times (0) then pause for 1.5 seconds;
- the LED will flash twice (2) then pause for 1.5 seconds;
- then the LED will flash 8 times (8) and stop

MENU MODE

You can enter the Menu mode to achieve your desired setting.

1. Press the Menu button to enter the menu mode.
2. Press the CH+/CH- or Vol+/Vol- button to select your desired setting. See the navigation functions of each key below:

KEY	MENU MODE
CH+	Channel Up
CH-	Channel Down
V-	Left
V+	Right

Note: (a) It will exit the Menu mode if no button is pressed in 60 seconds.
(b) In Menu mode, it will exit immediately if you press any button except theCH+/CH- or Vol+/Vol- button.

OPERATING THE REMOTE

1. Press and hold the ACTIVATE button for three seconds to turn on the remote. The LED will flash once.
2. Use the remote as you would any other remote.

Note: Make sure the INFRARED SENSOR is facing the device you want to control, and the remote itself is within 15 feet of the device with nothing blocking its path.

3. The remote will automatically enter the standby mode if no button is pressed within one minute. This means that you can press the buttons or lean on the remote, and it will not affect your devices.
4. Press and hold the ACTIVATE button for three seconds to wake up the remote and the LED will flash once. Then you can use the remote to control your devices.

CARE AND MAINTENANCE

- Spot clean only.
- Remove the batteries from the BATTERY COMPARTMENT if the remote will not be used for an extended period of time.

ONE (1) YEAR LIMITED WARRANTY

Brookstone® warrants this product against defects in materials and/or workmanship under normal use for a period of ONE (1) YEAR from the date of purchase by the original purchaser ("Warranty Period"). If a defect arises and a valid claim is received within the Warranty Period, at its option, Brookstone will either 1) repair the defect at no charge, using new or refurbished replacement parts, or 2) replace the product with a new product that is at least functionally equivalent to the original product, or 3) provide a store credit in the amount of the purchase price of the original product. A replacement product or part, including a user-installable part installed in accordance with instructions provided by Brookstone, assumes the remaining warranty of the original product. When a product or part is exchanged, any replacement item becomes your property and the replaced item becomes Brookstone's property. When a store credit is given, the original product must be returned to Brookstone and becomes Brookstone's property.

Obtaining Service: To obtain warranty service, call Brookstone Limited Warranty Service at 1-800-292-9819. Please be prepared to describe the product that needs service and the nature of the problem. A purchase receipt is required. All repairs and replacements must be authorized in advance. Service options, parts availability and response times will vary. You are responsible for delivery and the cost of delivery of the product or any parts to the authorized service center for replacement, per our instructions.

Limits and Exclusions: Coverage under this Limited Warranty is limited to the United States of America, including the District of Columbia and the U.S. Territories of Guam, Puerto Rico, and the U.S. Virgin Islands. This Limited Warranty applies only to products manufactured for Brookstone that can be identified by the "Brookstone" trademark, trade name, or logo affixed to them or their packaging. The Limited Warranty does not apply to any non-Brookstone products. Manufacturers or suppliers other than Brookstone may provide their own warranties to the purchaser,

but Brookstone, in so far as permitted by law, provides these products "as is." This warranty does not apply to: a) damage caused by failure to follow instructions relating to product's use or the installation of components; b) damage caused by accident, abuse, misuse, fire, floods, earthquake or other external causes; c) damage caused by service performed by anyone who is not a representative of Brookstone; d) accessories used in conjunction with a covered product; e) a product or part that has been modified to alter functionality or capability; f) items intended to be periodically replaced by the purchaser during the normal life of the product including, without limitation, batteries or light bulbs; g) any product sold "as is" including, without limitation, floor demonstration models and refurbished items; or h) a product that is used commercially or for a commercial purpose.

BROOKSTONE SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW, BROOKSTONE DISCLAIMS ANY AND ALL STATUTORY OR IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND WARRANTIES AGAINST HIDDEN OR LATENT DEFECTS. IF BROOKSTONE CANNOT LAWFULLY DISCLAIM STATUTORY OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, ALL SUCH WARRANTIES SHALL BE LIMITED IN DURATION TO THE DURATION OF THIS EXPRESS WARRANTY.

Some states disallow the exclusion or limitation of incidental or consequential damages or how long an implied warranty lasts, so the above exclusions or limitations may not apply to you. This warranty gives you specific legal rights and you may also have other rights, which vary from state to state.

Brookstone®

TV Pillow Remote

CODE BOOK

TABLE OF CONTENTS

TV Codes..... 2-23
- LCD/ACL TV..... 2-16
- DLP TV..... 16-17
- HDTV..... 17-18
- LCD/ACL 18-20
- PLASMA..... 20-22
- TV-DVD Combos..... 22
- TV-VCR-DVD Combos..... 22-23
- TV-VCR Combos..... 23

VCR Codes..... 23-32
- VCR..... 23-30
- DVRS..... 30-31
- TV-VCR 31
- TV-VCR.DVD 32

DVD Codes..... 32-37
- DVD..... 32-35
- DVD-R..... 35
- TV-DVD Combos..... 36
- TV-VCR-DVD Combos..... 36
- Blu-ray DVD Disc/HD-DVD player..... 36-37

Audio Codes..... 37-40
- Amplifier..... 37
- Receiver..... 37-38
- Audio accessories..... 38
- CD Player..... 38-39
- MD/DAT..... 39
- Hifi..... 39
- LD..... 39
- Tape..... 39-40

Cable Codes..... 40-43
- Cable..... 40-41
- Analog Cable..... 41
- Digital Cable..... 41
- DVR-Combos..... 41-42
- DTV 42
- Video 42-43

SAT Codes..... 43-48
- SAT..... 43-47
- DVR Combos..... 47-48

LIST OF CODES

TV CODES

LCD/ACL TV

ACCURIAN	0410				
ACTION	0277	0148			
ACURA	0148				
ADMIRAL	0231	0459	0002	0014	0009
	0160				
ADVENT	0468	0472	0474	0475	0262
	0511	0011	0047	0055	0056
	0057	0069			
ADVENT	0087	0089	0094	0099	0105
	0111	0114	0201	0024	0066
ADYSON	0013				
AGAZI	0160				
AIKO	0453	0148			
AIM	0168				
AIOSTAY	0148				
AIWA	0141	0146	0147		
AKAI	0255	0386	0244	0448	0463
	0300	0387	0510	0417	0431
	0445	0003			
AKAI	0148	0168	0160	0179	0180
	0181	0218			
AKURA	0148	0179	0160	0199	0200
ALBA	0148	0201	0202	0011	0047
	0055	0056	0057	0069	0087
	0089	0094			
ALBA	0099	0105	0111	0114	
ALBATRON	0464	0263			
AMERICA ACTION	0235				
AMPRO	0536				
AMSTRAD	0179	0148	0160	0207	0208
	0011	0047	0055	0056	0057
	0069	0087			
AMSTRAD	0114	0224	0201	0089	0094
	0099	0105	0111		
ANAM	0235	0148			
ANGAL	0148	0160	0179		
ANHUA	0135	0173			
ANITECH	0148	0160	0179		
ANSONIC	0148	0179	0168		
ANTAREX	0148				
AOC	0448	0344	0372	0428	0012
	0144	0142	0148		
AOLINPIYA	0160	0179	0180	0181	
AOMNI	0379				
APEX DIGITAL	0467	0484	0469	0470	0284
	0302	0513	0522	0019	0052
	0059	0060			
APEX DIGITAL	0112	0125	0134	0146	
ARISTONA(PHILIPS)	0168				
ART-TECH	0148				
ASTAR	0366				
ASTRA	0148				
ATORO	0148				
AUDINAC	0034				
AUDIOSONIC	0160				
AUDIOTON	0160	0148			
AUDIOVOX	0458	0235	0453	0462	0246
	0252	0265	0278	0314	0418
	0420	0421			
AUDIOVOX	0163	0167			
AVENTURA	0233				
AWA	0168	0148			
AXION	0418				
BAIHEHUA	0145	0152	0153	0163	0165
	0166	0169	0170	0148	

BAIHUA	0148	0160	0179	0180	0181
BAILE	0144	0148	0154	0155	0156
	0157	0158	0159	0168	
BAIRD	0215				
BAOLESHI	0160	0179	0180	0181	
BAOSHENG	0143	0148			
BASIC LINE	0168	0148			
BAUR	0197	0221	0011	0047	0055
	0056	0057	0069	0087	0201
	0111	0114			
BAUR	0089	0094	0099	0105	
BEI JING	0143	0144	0145	0148	0152
	0153	0154	0155	0160	0163
	0165	0169			
BEI JING	0170	0179	0180	0181	0156
	0157	0158	0159	0168	
BEKO	0199				
BELL&HOWELL	0455	0014	0009	0038	
BENQ	0288	0329			
BEON	0201	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
BEON	0111	0114			
BPL	0214				
BRADFORD	0235				
BROKSONIC	0457	0459	0417	0512	0003
	0012	0072			
BUSH	0201	0200	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
BUSH	0105	0111	0114		
BUSH(ATAKI)	0148	0168			
BYD:SIGN	0326	0327			
CADIA	0313				
CAI HONG	0148				
CANDLE	0448				

CAPEHART	0142				
CARNIVALE	0448				
CARVER	0450				
CASCADE	0148				
CATHAY	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
CATHAY	0114	0201			
CELEBRITY	0229				
CELERA	0469				
CELERA	0019	0052	0059	0060	0112
	0125	0134	0146		
CENTURION	0142	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
CENTURION	0111	0114	0201		
CHAI XING	0145	0152	0153	0163	0165
	0166	0169	0170		
CHANG CHENG	0135	0143	0144	0145	0148
	0152	0153	0160	0163	0159
	0158	0157			
CHANG CHENG	0179	0180	0181	0154	0155
	0156				
CHANG FEI	0143	0168	0148		
CHANG FENG	0143	0160	0179	0180	0181
	0171	0172	0153		
CHANG HAI	0143	0148			
CHANG HONG	0469	0111	0112	0118	0124
	0125	0129	0113	0115	0128
	0130	0182			
CHANG HONG	0183	0181	0141	0163	0165
	0166	0169	0170	0179	0180
	0143	0145			
CHANG HONG	0148	0152	0153	0154	0156
	0160	0110	0052	0059	0060
	0134	0146			

CHANG HONG	0019						0451	0244	0448	0454	0533
CHENG DU	0143	0148					0460	0490			
CHUN FENG	0160	0179	0180	0181	0148	CURTIS MATHES	0500	0045			
CHUN SUN	0143	0148				CURTIS MATHIS	0003	0019	0034		
CIE	0168					CXC	0235				
CIMLINE	0148					CYBERHOME	0250				
CINEGO	0521					CYTRON	0498				
CITIZEN	0451	0448	0453	0417		DA XI GU	0148				
CITY COM	0148					DA YU	0142	0144	0159	0168	
CLARION	0235					DAEWOO	0458	0453	0508	0462	0238
CLARIVOX	0011	0047	0055	0056	0057		0463	0035	0036	0003	0041
	0069	0087	0089	0094	0099		0029	0148			
	0105	0111				DAEWOO	0144	0159	0168	0198	0210
CLARIVOX	0114	0201					0011	0047	0055	0056	0057
CLATRONIC	0160	0148					0069	0087			
CME	0148					DAEWOO	0089	0094	0099	0105	0111
COBY	0429						0114	0201			
COMMERCIAL SOLUTIONS	0351	0230				DANSAI	0160	0011	0047	0055	0056
CONCORDE	0148						0057	0069	0087	0089	0094
CONDOR	0148						0099	0105			
CONROWA	0142	0160	0179	0180	0181	DANSAI	0111	0114	0201		
	0134	0139	0140	0171	0172	DAYTRON	0013	0148	0168	0142	
	0174					DECCA	0201	0011	0047	0055	0056
CONTEC	0235	0148					0057	0069	0087	0089	0094
COSMEL	0148						0099	0105			
COSMOS	0148					DECCA	0111	0114			
CRAIG	0235	0022	0034	0020	0021	DEGRAAF	0147				
CROSLEX	0011					DELL	0309	0290	0296	0504	0412
CROSLEY	0450					DENON	0454				
CROWN	0235	0034	0198	0102	0122	DENVER	0148				
	0185	0215	0011	0047	0055	DIAMOND	0168				
	0056	0057				DIAMOND VISION	0524	0525			
CROWN	0069	0087	0089	0094	0099	DIGITAL LIFESTYLES	0403				
	0105	0111	0114	0201		DINASTY	0148				
CTC CLATRONIC	0179	0148				DIXI	0148	0011	0047	0055	0056
CURTIS MATHES	0230	0450	0455	0458	0231		0057	0069	0087	0089	0094

	0099	0105			
DIXI	0111	0114	0201		
DONG BAO	0148	0160	0179	0180	0181
DONG DA	0148				
DONG DI SHI	0148				
DONG HAI	0148				
DONG SHAN	0148	0142			
DST	0148				
DUAL-TEC	0148				
DUMONT	0530	0010			
DURABRAND	0459	0235	0234	0233	0487
DWIN	0466				
DYNEX	0505	0430	0440	0042	
ELECTRO TECH	0148				
ELECTROBAND	0229				
ELECTROGRAPH	0399	0379			
ELECTROHOME	0459				
ELEKTA	0160	0148	0168	0179	
ELEMENT	0390				
ELIN	0148	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
ELIN	0111	0114	0201		
ELTA	0148	0179			
EMERSON	0413	0455	0457	0459	0235
	0234	0233	0462	0345	0509
	0514	0424			
EMERSON	0022	0013	0020	0021	0003
	0015	0042	0034	0142	0073
EMPREX	0349	0365	0403		
ENVISION	0448	0256	0344	0428	
EPSON	0477	0480	0496		
ERRES	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
ERRES	0114	0201			
ESA	0255	0233	0514	0424	0073
ETRON	0156	0148			
EURO-FEEL	0160				
EUROMAN	0160				
FAIRMOST	0148				
FEI LANG	0148				
FEI LU	0143	0148			
FEI YAN	0160	0179	0180	0181	0148
FEI YUE	0143	0145	0170	0152	0153
	0163	0165	0166	0169	
FENNER	0168	0148			
FERGUSON	0102	0122	0185	0215	0011
	0047	0055	0056	0057	0069
	0087	0089			
FERGUSON	0094	0099	0105	0111	0114
	0201				
FIDELIS	0148				
FIDELITY	0148	0201			
FINLUX	0201	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
FINLUX	0111	0114			
FIRST LINE	0148	0168			
FISHER	0455	0025	0148		
FLEX VISION	0246				
FORMENTI	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
FORMENTI	0114	0201			
FORMENTI-PHOENIX	0179				
FRONTECH	0148	0160	0013		
FU LI	0173				
FU RI	0139	0143	0145	0147	0152
	0153	0156	0160	0161	0163
	0165	0166			
FU RI	0169	0170	0179	0180	0181

	0185	0186			
FUJITSU	0253	0240	0268	0427	0174
FUNAI	0235	0233	0310	0424	0160
	0148	0179			
FUTURETECH	0235				
G.E	0142	0144			
GANXIN	0143	0145	0152	0153	0163
	0165	0166	0167	0169	0170
GATEWAY	0399	0285	0286	0287	0400
GBC	0148	0168			
GE	0351	0230	0449	0458	0234
	0500	0045	0192	0313	0371
GEC	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
GEC	0114	0201			
GELOSO	0148	0168			
GENERAL ELECTRIC	0002	0018	0003	0007	0045
GENERAL TECHNIC	0148	0168			
GENEXXA	0200				
GFM	0233	0509	0424	0438	
GIBRALTER	0530	0448	0010		
GMG	0148	0179			
GO VIDEO	0281				
GOLDSTAR	0234	0448	0201	0011	0047
	0055	0056	0057	0069	0087
	0089	0094			
GOLDSTAR	0099	0105	0111	0114	
GOLDSTAR(LG)	0152	0142	0153	0163	0165
	0166	0169	0170	0148	0179
	0141	0145			
GOLDSTAR(LG)	0030	0046	0050	0051	0049
	0003	0013	0012		
GOODMANS	0168	0160	0148	0201	0013
	0011	0047	0055	0056	0057
	0069	0087			

GOODMANS	0089	0094	0099	0105	0111
	0114				
GPM	0166				
GRANADA	0168	0213	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
GRANADA	0105	0111	0114	0201	
GRANDIN	0148				
GRUNPY	0235				
HAI HONG	0154	0155	0156	0157	0158
	0148				
HAI LE	0173				
HAI YAN	0143	0145	0152	0153	0160
	0163	0165	0166	0169	0170
	0179	0180			
HAI YAN	0181				
HAIER	0487	0397	0398	0077	0078
HALIFAX	0160				
HALLMARK	0234				
HANNSPREE	0341	0342	0501		
HANSEATIC	0148	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
HANSEATIC	0111	0114	0201		
HARMAN/KARDON	0450				
HARSPER	0299				
HARVARD	0235				
HAVERMY	0231				
HCM	0148	0160			
HELIOS	0274				
HELLO KITTY	0458				
HEMA	0148				
HEWLETT PACKARD	0356	0291	0292	0293	0360
HILINE	0160				
HINARI	0148	0179	0198	0011	0047
	0055	0056	0057	0069	0087

	0089	0094			
HINARI	0099	0105	0111	0114	0201
HISENSE	0467	0079	0080	0081	0082
	0083	0084	0085	0134	0139
	0140	0142			
HISENSE	0146	0147	0171	0172	0148
HISONIX	0148				
HITACHI	0383	0489	0454	0251	0423
	0147	0139	0142	0140	0174
	0155	0134			
HITACHI	0032	0031	0013	0003	0068
HONG MEI	0136	0143	0145	0148	0149
	0152	0153	0160	0163	0165
	0166	0169			
HONG MEI	0170	0179	0180	0181	0141
	0182	0183			
HONG YAN	0143	0160	0179	0180	0181
HP	0356	0291	0292	0293	0360
HUA FA	0139	0148			
HUA QIANG	0160	0179	0180	0181	
HUA RI	0139	0160	0179	0180	0181
HUAN YU	0143	0145	0147	0152	0153
	0160	0163	0165	0166	0169
	0170	0179			
HUAN YU	0182	0183	0168	0180	0181
	0141				
HUANG HAI MEI	0143	0145	0148	0152	0153
	0163	0165	0166	0169	0170
HUANG LONG	0148				
HUANG SHAN	0143	0145	0148	0152	0153
	0160	0163	0165	0166	0169
	0170	0179			
HUANG SHAN	0180	0181			
HUMAX	0195				
HUODSTEJI	0135	0173			
HYPER VISION	0148				
HYPSON	0160	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
HYPSON	0111	0114	0201		
HYUNDAI	0267	0303	0320		
ICE S	0148	0160	0179		
ILO	0316	0377	0509	0388	0025
IMPEERIAL COWN	0148				
IMPERIAL	0160	0179	0180	0181	0144
	0154	0155	0156	0157	0158
	0159	0168			
IMPERIAL	0148	0102	0122	0185	0215
INDIANA	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
INDIANA	0114	0201			
INFINITY	0450				
INGERSOL	0148				
INITIAL	0377	0425			
INSIGNIA	0367	0233	0298	0498	0361
	0424	0526	0430	0529	
INTEQ	0530				
INTEQ	0010				
INTERFUNK	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
INTERFUNK	0114	0201			
INTERVISION	0160	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
INTERVISION	0111	0114	0201		
IRIS	0442				
IRRADIO	0148				
ITS	0160				
ITT/NOKA	0168				
JBL	0450				

JC PENNY	0003	0002	0030	0007	
JCB	0229				
JENSEN	0468	0474	0475	0323	0511
	0114	0201	0024	0066	0089
	0094	0099			
JENSEN	0105	0111	0011	0047	0055
	0056	0057	0069	0087	
JIA CAI LI	0148	0160	0179	0180	0181
JIA HUA	0173	0135			
JIEN	0148				
JIN FENG	0135	0143	0150	0151	
JIN HAI	0141	0182	0183		
JING TA	0145	0148	0152	0153	0163
	0165	0166	0169	0170	0179
	0180	0181			
JING TA	0141	0182	0183		
JINQUE 1	0160	0179	0180	0181	0148
JINQUE 2	0143	0148			
JINXING	0165	0166	0142	0139	0143
	0145	0147	0152	0153	0154
	0160	0163			
JINXING	0180	0181	0169	0170	0179
JNC	0194				
JU HUA	0143	0145	0152	0153	0160
	0163	0165	0166	0169	0170
	0179	0180			
JU HUA	0181				
JVC	0531	0247	0494	0375	0408
	0028	0137	0204	0102	0122
	0185	0215			
KAI GE	0143	0145	0148	0152	0153
	0160	0163	0165	0166	0169
	0170	0179			
KAI GE	0180	0181			
KAISUI	0148				
KANG HONG	0134	0183	0182		
KANG LI	0155	0144	0154	0156	0158
	0159	0160	0148		
KANG LI 2	0145	0148	0152	0153	0163
	0165	0166	0169	0170	0143
	0154	0155			
KANG LI 2	0156	0157	0158	0138	
KANG YI	0148	0160	0179	0180	0181
KATA	0131				
KAYA	0148				
KDS	0358	0390			
KEC	0235				
KENDO	0148	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
KENDO	0111	0201	0114	0224	0290
KENWOOD	0448				
KIMAY	0179				
KLH	0469	0470	0520	0019	0052
	0059	0060	0112	0125	0134
	0146				
KOLSTER	0179				
KONDA	0148				
KONG QUE	0143	0145	0148	0152	0153
	0160	0163	0165	0166	0167
	0169	0170			
KONIG	0148				
KONKA	0088	0096	0100	0101	0102
	0103	0104	0116	0117	0122
	0123	0127			
KONKA	0128	0130	0110	0111	0112
	0113	0143	0145	0148	0132
	0152	0153			
KONKA	0154	0180	0181	0187	0188
	0189	0156	0157	0179	0161
	0163	0165			
KONKA	0166	0169	0170	0190	

KORPEL	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
KORPEL	0201	0114			
KOST	0308	0355			
KOYODA	0148				
KTV	0235	0448	0033	0013	0003
	0034				
KUAI LE	0148	0160	0179	0180	0181
KUN LUN	0135	0143	0150	0151	0160
	0144	0168	0166	0165	0148
LE HUA	0143	0145	0148	0152	0153
	0163	0165	0166	0169	0170
LENCO	0148	0168			
LENOIR	0148	0179	0168		
LEYCO	0160	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
LEYCO	0111	0201	0114		
LG	0350	0234	0464	0271	0296
	0497	0406	0426	0003	0006
	0012	0058			
LG	0142	0216			
LG (GOLDSTAR)	0179	0148	0169	0170	
LI HUA	0143				
LIESENK & TTER	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
LIESENK & TTER	0201	0114			
LIFETEC	0148	0160			
LLOYDS	0148				
LLOYTRON	0013				
LOEWE	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
LOEWE	0201	0114			
LONG JIANG	0143	0160	0179	0180	0181
LXI	0230	0450	0455	0456	0234
LXI(SEARS)	0002	0003	0011	0025	0019
	0012	0052			
M ELECTRONIC	0168	0148	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
M ELECTRONIC	0105	0111	0201	0114	
MAG	0358	0390			
MAGNAVOX	0352	0414	0450	0448	0465
	0252	0297	0495	0344	0364
	0514	0424			
MAGNAVOX	0425	0011	0012	0013	0003
	0043	0047	0142	0079	0091
	0205	0209			
MANCHENGFU	0148	0159	0142		
MANDOR	0160				
MANESTH	0160				
MARANTZ	0450	0448	0245	0269	0270
	0491	0346	0024	0079	0091
	0252	0314			
MARANTZ	0394	0205	0209	0011	0047
	0055	0056	0057	0069	0087
	0089	0094			
MARANTZ	0099	0105	0111	0390	0201
	0114				
MARK	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
MARK	0201	0114			
MARSHALL	0148				
MATCH ITALIA	0148				
MATSUI	0148	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
MATSUI	0111	0201	0114		

MATSUSHITA	0236	0237			
MAXELL	0148				
MAXENT	0399	0248	0301	0401	
MAXON	0148				
MEDIATOR	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
MEDIATOR	0201	0114			
MEGAPOWER	0464				
MEGATRON	0234	0454			
MEILE	0143	0145	0152	0153	0160
	0163	0165	0166	0169	0170
	0179	0180			
MEILE	0181	0141	0182	0183	
MELECTRONIC	0168				
MEMOREX	0455	0459	0232	0234	0166
	0148	0142	0198		
MEMPHIS	0148				
MENGMEI	0145	0152	0153	0163	0165
	0166	0169	0170		
MGA	0232	0234	0448		
MIDLAND	0230	0530	0449	0156	0159
	0010				
MINTEK	0377	0425			
MITSUBISHI	0305	0231	0232	0234	0261
	0483	0507	0066	0108	0143
	0177	0024			
MITSUBISHI	0055	0056	0057	0069	0087
	0089	0094	0099	0105	0111
	0011	0047			
MITSUBISHI	0201	0114			
MITSUBISHI/MGA	0142	0168	0144	0143	0177
	0024	0003	0012	0066	
MONIVISION	0464	0263			
MOTOROLA	0231	0260			
MOXELL	0260				
MTC	0451	0448	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
MTC	0105	0111	0201	0114	
MUDAN	0135	0184	0143	0145	0148
	0150	0151	0160	0163	0165
	0166	0169			
MUDAN	0170	0179	0180	0181	
MULTITECH	0235	0148			
NAD	0456	0234	0482	0492	0019
	0052	0059	0060	0112	0125
	0134	0146			
NANBAO	0148	0183	0160	0179	0180
	0181	0141	0182		
NANSHENG	0143	0160	0179	0180	0181
NARITA	0168				
NATIONAL	0135	0150	0151	0155	0156
	0157	0158	0159	0173	0144
	0154	0148			
NEC	0448	0461	0485	0346	0391
	0168	0137	0142	0143	0148
	0153	0155			
NEC	0179	0180	0181	0003	0012
NECKERMANN	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
NECKERMANN	0201	0114			
NEI	0201	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
NEI	0111	0114			
NETTV	0399	0248			
NEWTECH	0148				
NEXUS ELECTRONICS	0439				
NIKKAI	0148	0160	0013	0011	0047
	0055	0056	0057	0069	0087

	0089	0094				PALLADIUM	0102	0122	0185	0215	
NIKKAI	0290	0201	0111	0114	0099	PALSONIK	0148				
	0105					PANAMA	0160	0148			
NIKKO	0234	0448	0453			PANASONIC	0236	0354	0449	0237	0319
NIKON	0141	0182	0183				0419	0516	0517	0203	0142
NOBLEX	0168	0148					0148	0151			
NOKIA	0102	0122	0185	0215		PANASONIC	0018	0016	0007	0049	0067
NORCENT	0467	0259	0292	0344	0371		0074	0076	0184	0135	0146
	0372	0373					0147	0150			
NORWOOD MICRO	0316	0321	0324			PANDA	0135	0143	0145	0148	0150
NOVATRONIC	0168	0148					0151	0152	0153	0156	0160
NTC	0453						0163	0165			
NUVISION	0385	0437				PANDA	0166	0169	0170	0179	0180
OKANO	0148						0181	0141	0182	0183	
OLEVIA	0378	0295	0304	0337		PARK	0443	0444			
OLYMPUS	0499					PAUSA	0148				
ONCEAS	0148					PENNEY	0230	0456	0449	0451	0234
ONWA	0235						0448	0500	0142	0045	
OPTIMUS	0236	0455	0533	0237		PEONY	0097				
OPTOMA	0282					PERDIO	0168				
OPTONICA	0231					PETTERS	0362				
ORAVA/OTF	0148					PHASE	0013				
ORION	0457	0459	0505	0148	0142	PHILCO	0450	0448	0011	0013	0003
	0042	0201	0114	0094	0099		0068	0035	0031	0148	
	0105	0111				PHILIPS	0352	0450	0243	0491	0355
ORION	0011	0047	0055	0056	0057		0396	0415	0168	0209	0205
	0069	0087	0089				0163	0165			
OSAKI	0160	0179	0013			PHILIPS	0011	0056	0043	0017	0166
OSUME	0013						0169	0170	0145	0152	0153
OTAKE	0013						0079	0091			
OTHERS	0192	0193	0196	0148	0142	PHILIPS	0111	0201	0114	0047	0055
OTTO VERSAND	0197	0221	0201	0089	0094		0057	0069	0087	0089	0094
	0011	0047	0055	0056	0057		0099	0105			
	0069	0087				PHONOLA	0011	0047	0055	0056	0057
OTTO VERSAND	0105	0111	0114	0099			0069	0087	0089	0094	0099
PADIOTONE	0148						0105	0111			

PHONOLA	0201	0114			
PILOT	0448				
PIONEER	0353	0533	0239	0482	0307
	0346	0037	0018	0019	
PLANAR	0357				
PLANTRON	0148	0160			
POLAROID	0362	0469	0435	0434	0433
	0526	0523	0522	0520	0407
	0405	0404			
POLAROID	0390	0358	0339	0335	0334
	0498	0330	0328	0316	0311
	0308	0274			
POLAROID	0134	0146	0019	0052	0059
	0060	0112	0125		
POPPY	0148				
PORTLAND	0453	0003	0008		
PRIMA	0468	0472	0474	0475	0511
	0160	0148	0179	0011	0047
	0055	0056			
PRIMA	0094	0099	0105	0111	0114
	0201	0024	0066	0057	0069
	0087	0089			
PRINCETON	0464				
PRISM	0449				
PROFEX	0148				
PROLINE	0201				
PROSCAN	0351	0230	0500	0436	0447
	0045				
PROSONIC	0168				
PROTECH	0160	0148	0201	0102	0122
	0185	0215	0011	0047	0055
	0056	0057			
PROTECH	0111	0114	0201	0094	0099
	0105	0069	0087	0089	
PROTON	0234	0460	0142		
PROTRON	0332	0333			

PROVIEW	0260	0358	0390		
PULSAR	0530	0010			
PUNEET	0365				
PYE	0168	0209			
PYMI	0148				
QIN DAO	0135	0143	0150	0151	0160
	0179	0180	0181		
QIN YUN	0148				
QUASAR	0236	0449	0237	0018	0007
	0048				
QUELLE	0197	0221	0105	0111	0114
	0011	0047	0055	0056	0057
	0069	0087			
QUELLE	0201	0089	0094	0099	
R LINE	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
R LINE	0201	0114			
RADIO SHACK	0230	0455	0235	0234	0448
	0002	0012	0024	0023	
RADIOLA	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
RADIOLA	0201	0114			
RCA	0506	0351	0230	0532	0239
	0488	0490	0493	0500	0409
	0518	0519			
RCA	0422	0526	0441	0446	0045
RCA/PROSCAN	0002	0003	0004	0005	0006
	0007	0008	0044	0045	0046
	0053				
REALISTIC	0455	0235	0234	448	0156
	0163				
REVOLUTION HD	0379				
REVOX	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099

	0105	0111				SCEPTRE	0279	0302	0343	0374	
REVOX	0201	0114				SCHAUB LORENZ	0148	0168			
REX	0160					SCHNEIDER	0201	0168	0148	0011	0047
ROADSTAR	0148	0198	0102	0122	0185		0055	0056	0057	0069	0087
	0215						0089	0094			
RUNCO	0530	0448	0461	0535	0346	SCHNEIDER	0099	0105	0111	0114	
	0381	0010				SCOTCH	0234				
RUYI	0143	0145	0147	0152	0153	SCOTT	0457	0235	0234	0392	0034
	0163	0165	0166	0169	0170		0012	0142			
SAI GE	0143	0148				SEARS	0230	0450	0455	0456	0234
SAISHO	0160	0148					0233	0142			
SAMPO	0399	0448	0248	0142	0148	SEG	0160	0148			
SAMSUNG	0255	0451	0244	0234	0448	SEI	0197	0221			
	0249	0257	0289	0368	0510	SEIKO	0168				
	0205	0206				SETRON	0148				
SAMSUNG	0160	0148	0142	0170	0164	SHAN CHA	0143	0160	0179	0180	0181
	0165	0166	0169	0012	0013	SHAN YANG	0148				
	0003	0055				SHANG HAI	0143	0145	0148	0152	0153
SAMSUNG	0026	0105	0111	0011	0047		0160	0163	0165	0166	0169
	0290	0056	0057	0069	0087		0170	0179			
	0089	0094				SHANG HAI	0141	0180	0181	0182	0183
SAMSUNG	0201	0114	0218	0099		SHAO FENG	0143	0147	0134	0139	0152
SAN YUAN	0136	0143	0145	0148	0149	SHARP	0258	0231	0534	0241	0242
	0152	0153	0163	0165	0166		0481	0376	0014	0013	0015
	0169	0170					0070	0136			
SANJIAN	0160	0179	0180	0181		SHARP	0148	0149	0212	0211	
SANSUI	0459	0348	0417			SHEN YANG	0143	0148	0172	0171	0160
SANYO	0455	0452	0473	0486	0294	SHENCAI	0139	0148	0160	0179	0180
	0025	0023	0054	0213	0180		0181				
	0181	0137				SHENG CHIA	0231				
SANYO	0148	0140	0134	0139	0146	SHERWOOD	0347	0148			
	0147	0160	0162	0179		SHOV	0148				
SBR	0168	0011	0047	0055	0056	SIEMENS	0011	0047	0055	0056	0057
	0057	0069	0087	0089	0094		0069	0087	0089	0094	0099
	0099	0105					0105	0111			
SBR	0201	0114	0111			SIEMENS	0201	0114			

SIGNATURE 2000	0014	0009	0142		
SIGNET	0308				
SILMA	0148				
SILVER	0148	0179			
SIM2 MULTIMEDIA	0322				
SIMPSON	0148				
SINGER	0168				
SINUDYNE	0148	0197	0221		
SKYWORTH	0091	0092	0099	0105	0106
	0113	0114	0115	0119	0120
	0126	0118			
SKYWORTH	0130	0185	0171	0172	0145
	0148	0152	0185	0153	0163
	0165	0166			
SKYWORTH	0169	0170			
SOLAVOX	0013				
SOLE	0355	0379			
SONGBA	0148				
SONOKO	0148	0160	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
SONOKO	0201	0114	0105	0111	
SONTEC	0148	0011	0047	0055	0056
	0057	0069	0087	0089	0094
	0099	0105			
SONTEC	0111	0201	0114		
SONY	0229	0254	0478	0331	0389
	0197	0163	0165	0166	0169
	0170	0001			
SONY	0148	0167	0175	0138	0145
	0153	0221			
SOUND&VISION	0168				
SOUNDESIGN	0235	0234	0142		
SOUNDMASTER	0148				
SOUNDWAVE	0102	0122	0185	0215	0011
	0047	0055	0056	0057	0069
	0087	0089			
SOUNDWAVE	0111	0114	0201	0094	0099
	0105				
SOVA	0332	0421			
SOWA	0148	0142			
SOYO	0365	0411			
SPECTRONIQ	0358	0390			
SQUAREVIEW	0233				
SSS	0235	0155	0179	0180	0181
STANDARD COMP	0148	0168			
STAR LITE	0235	0148			
STUDIO EXPERIENCE	0263				
SUPERSCAN	0231	0273			
SUPERTEC	0148				
SUPRA	0168	0148			
SUPREME	0229				
SUTRON	0148				
SVA	0467	0274	0275	0276	
SYC LINE	0148				
SYLVANIA	0413	0450	0448	0233	0310
	0328	0509	0416	0514	0424
	0345	0073			
SYLVANIA	0011	0012	0003		
SYMPHONIC	0235	0233	0514	0023	0039
	0040	0034	0073		
SYNCO	0142				
SYNTAX	0378	0295	0304	0337	
SYSLINE	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
SYSLINE	0201	0114			
TAI SHAN	0143	0148	0168	0159	0158
	0157	0156	0155		
TAIYI	0148				
TANDY	0231	0200			
TATUNG	0293	0315	0316	0317	0318

	0503	0400	0148	0201	0114	TONG GUANG	0160	0179	0180	0181	
	0105	0111				TOSHIBA	0363	0455	0456	0306	0451
TATUNG	0011	0047	0055	0056	0057		0515	0417	0391	0384	0382
	0069	0087	0089	0094	0099		0502	0340			
TCL	0132	0086	0087	0089	0090	TOSHIBA	0497	0325	0492	0264	0476
	0093	0094	0095	0098	0107		0237	0181	0060	0019	0014
	0108	0109					0052	0059			
TCL	0121	0114	0115	0118	0119	TOSHIBA	0134	0139	0140	0146	0147
	0120	0153	0163	0165	0166		0148	0155	0156	0158	0160
	0169	0170					0179	0180			
TCL	0179	0180	0181	0172	0145	TOSHIBA	0075	0003	0006	0012	0058
	0152						0142	0216	0125	0112	
TEC	0148					TREVI	0148				
TECHNICS	0236	0449				TRUTECH	0394	0528			
TECHVIEW	0266					TVS	0459				
TECHWOOD	0449					ULTRA	0333	0159			
TECO	0148					ULTRAVOX	0168				
TEKNANT	0148					UNIDEN	0191				
TEKNIKA	0450	0235	0232	0451	0453	UNIVERSUM	0160	0011	0047	0055	0056
TELEFUNKEN	0244						0057	0069	0087	0089	0094
TELEGAZI	0160						0099	0105			
TELEOPTA	0148					UNIVERSUM	0201	0114	0111		
TELETECH	0148					US LOGIC	0316	0324			
TENGHUA	0148					UTAX	0148				
TENSAI	0148	0168	0013			VANGUARD	0148				
THORN	0102	0122	0185	0215	0011	VECO	0148				
	0047	0055	0056	0057	0069	VECTOR RESEARCH	0448				
	0087	0089				VESTEL	0011	0047	0055	0056	0057
THORN	0111	0114	0201	0094	0099		0069	0087	0089	0094	0099
	0105						0105	0111			
THORN FERGUSON	0148	0179				VESTEL	0201	0114			
TIANE	0136	0143	0149			VEXA	0148				
TMK	0234					VICTOR	0531				
TNCI	0530	0010				VIDECH	0031	0003	0012	0142	
TOBO	0148					VIDIKRON	0450	0346	0381		
TOKAI	0148					VIDION	0148				

VIDTECH	0234				
VIEWSONIC	0399	0251	0272	0273	0280
	0336	0499	0370	0380	0395
	0428	0432			
VIORE	0300	0388			
VISA	0148				
VISART	0338				
VIZIO	0402	0273	0280	0359	0400
WARDS	0450	0234	0448	0482	0492
	0013	0003	0015	0012	0142
	0134	0146			
WARDS	0019	0052	0059	0060	0112
	0125				
WARUMAIA	0159	0144	0168		
WATSON	0011	0047	0055	0056	0057
	0069	0087	0089	0094	0099
	0105	0111			
WATSON	0201	0114			
WAYCON	0456				
WEIPAI	0148				
WESTINGHOUSE	0393	0280	0283	0284	0312
	0369				
WHITE WESTINGHOUSE	0459	0462	0148	0011	0047
	0055	0056	0057	0069	0087
	0089	0094			
WHITE WESTINGHOUSE	0099	0105	0111	0201	0114
WINTERNITZ	0168				
WUNWOOD	0148				
WYSE	0344				
XHUHAI	0148				
XI HU	0143	0145	0152	0153	0160
	0163	0165	0166	0169	0170
	0179	0180			
XI HU	0181				
XIA HUA	0160	0179	0180	0181	0148
XIANG YANG	0160	0180	0181		
XIANG YU	0148				
XIN FU	0148				
XINAGHAI	0148	0160	0179	0180	0181
XINRISONG	0141	0182	0183		
XUELIAN	0145	0152	0153	0163	0165
	0166	0169	0170	0141	0182
	0183				
YAMAHA	0448	0471	0251	0477	0479
YINGGE	0145	0148	0152	0153	0163
	0165	0166	0169	0170	
YOKO	0148	0160	0011	0047	0055
	0056	0057	0069	0087	0089
	0094	0099			
YOKO	0105	0111	0201	0114	
YONG BAO	0141	0182	0183		
YONG GU	0145	0148	0152	0153	0163
	0165	0166	0169	0170	
YORK	0142				
YOULANASI	0143	0145	0152	0153	0163
	0165	0166	0169	0170	
YOUSIDA	0148	0141	0182	0183	
YU HANG	0148				
YUMATU	0148				
ZENITH	0530	0459	0234	0453	0009
	0010				
ZHU HAI	0148	0168			

DLP TV

HEWLETT PACKARD	0356				
HP	0356				
MAGNAVOX	0364	0011	0012		
	0013	0003	0043	0047	0142
	0079	0091	0205	0209	
MITSUBISHI	0305	0066	0108	0143	0177
	0024	0011	0047	0055	0056

	0057	0069					0013	0003			
MITSUBISHI	0087	0089	0094	0099	0105	HITACHI	0068				
	0111	0201	0114			MARANTZ	0269	0024	0079	0091	0099
OPTOMA	0282						0105	0111	0201	0069	0087
PANASONIC	0319	0018	0016	0007	0049		0089	0094			
	0067	0074	0076	0184	0135	MARANTZ	0114	0205	0209	0011	0047
	0146	0147					0055	0056	0057		
PANASONIC	0150	0203	0142	0148	0151	MITSUBISHI	0232	0222	0066	0108	0143
RCA	0351	0045					0177	0024	0011	0201	0105
SAMSUNG	0255	0289	0160	0148	0142		0111	0114			
	0170	0164	0165	0166	0169	MITSUBISHI	0047	0055	0056	0057	0069
	0012	0013					0087	0089	0094	0099	
SAMSUNG	0003	0055	0026	0205	0206	MOTOROLA	0223				
	0201	0114	0218	0094	0099	OLEVIA	0378				
	0105	0111				PANASONIC	0236	0237	0319	0018	0016
SAMSUNG	0011	0047	0290	0056	0057		0007	0049	0067	0074	0076
	0069	0087	0089				0184	0135			
SIM2 MULTIMEDIA	0322					PANASONIC	0146	0150	0147	0203	0142
SVA	0276						0148	0151			
TOSHIBA	0363	0325	0134	0139	0140	PIONEER	0239	0037	0018	0019	
	0146	0147	0148	0155	0156	PROSCAN	0224	0045			
	0158	0160				RCA	0351	0045			
TOSHIBA	0179	0180	0181	0060	0019	SAMSUNG	0255	0244	0225	0160	0148
	0014	0052	0059	0075	0216		0142	0170	0164	0165	0166
	0112	0125					0169	0012			
TOSHIBA	0003	0006	0012	0058	0142	SAMSUNG	0013	0003	0055	0026	0205
VIZIO	0359						0206	0011	0047	0111	0201
							0114	0218			
HDTV						SAMSUNG	0056	0057	0069	0087	0089
							0094	0099	0105		
ADVENT	0262	0011	0047	0055	0056	SHARP	0241	0242	0014	0013	0015
	0057	0069	0087	0089	0094		0070	0136	0148	0149	0212
	0099	0066					0211				
ADVENT	0105	0111	0114	0201	0024	SONY	0226	0148	0167	0175	0138
HITACHI	0423	0147	0139	0142	0140		0145	0153	0163	0165	0166
	0174	0155	0134	0032	0031		0169	0170			

SONY	0001	0197	0221		
SYLVANIA	0227	0011	0012	0003	0073
TOSHIBA	0306	0228	0134	0139	0140
	0146	0147	0148	0155	0156
	0158	0160			
TOSHIBA	0179	0180	0181	0060	0019
	0014	0052	0059	0075	0216
	0112	0125			
TOSHIBA	0003	0006	0012	0058	0142

LCD/ACL

ACCURIAN	0410				
ACTION	0277	0148			
AKAI	0386	0387	0417	0445	0218
	0003	0148	0168	0160	0179
	0180	0181			
AOC	0344	0428	0012	0144	0142
	0148				
AOMNI	0379				
APEX DIGITAL	0284	0302	0019	0052	0059
	0060	0112	0125	0134	0146
ASTAR	0366				
AUDIOVOX	0235	0246	0252	0265	0278
	0314	0418	0420	0421	0163
	0167				
BENQ	0329	0219	0250		
BYD:SIGN	0326	0327			
CADIA	0313				
CITIZEN	0417				
COBY	0429				
CYBERHOME	0250				
DELL	0309	0290	0296	0412	
DIGITAL LIFESTYLES	0403				
DYNEX	0430	0440	0042		
ELEMENT	0390				
EMERSON	0413	0345	0424	0022	0013
	0020	0021	0003	0015	0042
	0034	0142			
EMERSON	0073				
EMPREX	0349	0365	0403		
ENVISION	0256	0344	0428		
FLEXVISION	0246				
FUNAI	0233	0160	0148	0179	
GFM	0438				
GO VIDEO	0281				
HAIER	0397	0398	0077	0078	
HANNSPREE	0341	0342			
HARSPER	0299				
HEWLETT PACKARD	0291				
HITACHI	0383	0147	0139	0142	0140
	0174	0155	0134	0032	0031
	0013	0003			
HITACHI	0068				
HP	0291				
HUMAX	0195	0196			
HYUNDAI	0267	0303	0320		
ILO	0316	0377	0388	0425	
INITIAL	0377	0425			
INSIGNIA	0367	0298	0361	0526	0430
IRIS	0442				
JENSEN	0323				
JNC	0194				
JVC	0375	0408	0028	0137	0204
	0102	0122	0185	0215	
KOST	0308				
LCD TV	0192	0193			
LG	0350	0271	0296	0406	0426
	0216	0003	0006	0012	0058
	0142				
MAGNAVOX	0414	0252	0297	0344	0425
	0011	0012	0013	0003	0043

	0047	0142			
MAGNAVOX	0079	0091	0205	0209	
MARANTZ	0270	0024	0079	0091	0099
	0105	0111	0201	0114	0087
	0089	0094			
MARANTZ	0069	0205	0209	0011	0047
	0055	0056	0057		
MAXENT	0399	0248	0301	0401	
MINTEK	0377	0425			
MITSUBISHI	0305	0201	0114	0105	0111
	0066	0108	0143	0177	0024
	0011	0047			
MITSUBISHI	0055	0056	0057	0069	0087
	0089	0094	0099		
NETTV	0248				
NEXUS ELECTRONICS	0439				
NORCENT	0344	0371	0373		
NORWOOD MICRO	0316	0321			
NUVISION	0385	0437			
OLEVIA	0378	0295	0304	0337	0216
PANASONIC	0354	0237	0419	0018	0016
	0007	0049	0067	0074	0076
	0184	0135			
PANASONIC	0146	0147	0150	0203	0142
	0148	0151			
PARK	0443	0444			
PETTERS	0362				
PHILIPS	0352	0355	0396	0415	0011
	0056	0043	0017	0166	0169
	0170	0145			
PHILIPS	0152	0153	0163	0165	0168
	0209	0205	0301	0111	0079
	0091	0105			
PHILIPS	0201	0114	0099	0047	0055
	0057	0069	0087	0089	0094
PIONEER	0307	0037	0018	0019	
PLANAR	0357				
POLAROID	0362	0308	0311	0330	0339
	0358	0390	0404	0405	0407
	0433	0434			
POLAROID	0435	0019	0052	0059	0060
	0112	0125	0134	0146	
PROSCAN	0436	0447	0045		
PROTRON	0332	0333			
PUNEET	0365				
RCA	0230	0409	0422	0441	0446
	0045				
REVOLUTIONHD	0379				
RUNCO	0381	0010			
SAMPO	0399	0248	0142	0148	
SAMSUNG	0255	0249	0257	0368	0160
	0148	0142	0170	0164	0165
	0166	0169			
SAMSUNG	0012	0013	0003	0055	0026
	0205	0206	0201	0114	0218
	0105	0111			
SAMSUNG	0011	0047	0290	0056	0057
	0069	0087	0089	0094	0099
SANSUI	0348				
SANYO	0294	0148	0140	0134	0139
	0146	0147	0160	0162	0179
	0180	0181			
SANYO	0137	0025	0023	0054	0213
SCEPTRE	0279	0302	0343	0374	
SCOTT	0392	0034	0012	0142	
SHARP	0258	0231	0376	0217	0220
	0014	0013	0015	0070	0136
	0148	0149			
SHARP	0212	0211			
SHERWOOD	0347				
SIGNET	0308				
SOLE	0355	0379			

SONY	0254	0389	0221	0148	0167
	0175	0138	0145	0153	0163
	0165	0166			
SONY	0169	0170	0001	0197	
SOVA	0332				
SOYO	0365	0411			
SUPERSCAN	0273				
SVA	0275				
SYLVANIA	0413	0233	0310	0328	0345
	0416	0011	0012	0003	0073
SYMPHONIC	0233	0023	0039	0040	0034
	0073				
SYNTAX	0378	0295	0304	0337	
TATUNG	0316	0148	0201	0114	0057
	0069	0087	0089	0094	0099
	0105	0111			
TATUNG	0011	0047	0055	0056	
TECHVIEW	0266				
TOSHIBA	0363	0264	0340	0382	0384
	0134	0139	0140	0146	0147
	0148	0155			
TOSHIBA	0156	0158	0160	0179	0180
	0181	0060	0019	0014	0052
	0059	0075			
TOSHIBA	0003	0006	0012	0058	0142
	0216	0112	0125		
TRUTECH	0394				
ULTRA	0333	0159			
UNIDEN	0191				
US LOGIC	0316				
VIDIKRON	0346	0381			
VIEWSONIC	0272	0273	0280	0336	0370
	0380	0395	0428	0432	
VIORE	0388				
VISART	0338				
VIZIO	0402	0273	0280	0400	
WESTINGHOUSE	0393	0280	0283	0284	0312
	0369				
WYSE	0344				

PLASMA

AKAI	0255	0386	0300	0431	0003
	0148	0168	0160	0179	0180
	0181	0218			
ALBATRON	0263				
AOC	0372	0012	0144	0142	0148
AOMNI	0379				
BENQ	0288				
BYD:SIGN	0327	0288			
DAEWOO	0238	0035	0036	0003	0041
	0029	0148	0144	0159	0168
	0198	0210			
DAEWOO	0094	0099	0105	0111	0011
	0047	0055	0056	0057	0069
	0087	0089			
DAEWOO	0114	0201			
DELL	0309	0412			
ELECTROGRAPH	0399	0379			
ESA	0255	0073			
FUJITSU	0253	0240	0268	0427	0174
FUNAI	0310	0160	0148	0179	
GATEWAY	0399	0285	0286	0287	0400
HAIER	0397	0077	0078		
HARSPER	0299				
HELIOS	0274				
HEWLETT PACKARD	0292	0360			
HITACHI	0383	0251	0147	0139	0142
	0140	0174	0155	0134	0032
	0031	0013			
HITACHI	0003	0068			
HP	0292	0360			

ILO	0388				
INSIGNIA	0367				
JVC	0247	0028	0137	0204	0102
	0122	0185	0215		
LG	0350	0234	0271	0216	0003
	0006	0012	0058	0142	
MAGNAVOX	0414	0011	0012	0013	0003
	0043	0047	0142	0079	0091
	0205	0209			
MARANTZ	0245	0346	0024	0079	0091
	0105	0111	0201	0114	0087
	0089	0094			
MARANTZ	0099	0205	0209	0011	0047
	0055	0056	0057	0069	
MAXENT	0399	0401			
MITSUBISHI	0261	0201	0114	0105	0111
	0066	0108	0143	0177	0024
	0011	0047			
MITSUBISHI	0055	0056	0057	0069	0087
	0089	0094	0099		
MONIVISION	0263				
MOTOROLA	0260				
MOXELL	0260				
NEC	0346	0391	0168	0137	0142
	0143	0148	0153	0155	0179
	0180	0181			
NEC	0003	0012			
NETTY	0399				
NEXUS ELECTRONICS	0439				
NORCENT	0259	0292	0372		
NORWOOD MICRO	0324				
PANASONIC	0236	0354	0237	0018	0016
	0007	0049	0067	0074	0076
	0184	0135			
PANASONIC	0146	0147	0150	0203	0142
	0148	0151			
PHILIPS	0243	0396	0011	0056	0043
	0017	0166	0169	0170	0145
	0152	0153			
PHILIPS	0163	0165	0168	0209	0205
	0079	0091	0301	0111	0201
	0114	0105			
PHILIPS	0047	0055	0057	0069	0087
	0089	0094	0099		
PIONEER	0353	0239	0307	0346	0037
	0018	0019			
POLAROID	0274	0311	0334	0335	0134
	0146	0019	0052	0059	0060
	0112	0125			
PROVIEW	0260				
PUNEET	0365				
REVOLUTIONHD	0379				
RUNCO	0346	0010			
SAMPO	0399	0142	0148		
SAMSUNG	0255	0160	0148	0142	0170
	0164	0165	0166	0169	0012
	0013	0003			
SAMSUNG	0055	0026	0205	0206	0201
	0114	0218	0089	0094	0099
	0105	0111			
SAMSUNG	0011	0047	0290	0056	0057
	0069	0087			
SANYO	0294	0148	0140	0134	0139
	0146	0147	0160	0162	0179
	0180	0181			
SANYO	0137	0025	0023	0054	0213
SOLE	0379				
SONY	0229	0254	0331	0148	0167
	0175	0138	0145	0153	0163
	0165	0166			
SONY	0169	0170	0001	0197	0221
STUDIO EXPERIENCE	0263				

SVA	0274				
SYLVANIA	0310	0345	0011	0012	0003
	0073				
TATUNG	0293	0315	0317	0318	0400
	0148	0201	0114	0094	0099
	0105	0111			
TATUNG	0011	0047	0055	0056	0057
	0069	0087	0089		
TOSHIBA	0237	0391	0134	0139	0140
	0146	0147	0148	0155	0156
	0158	0160			
TOSHIBA	0179	0180	0181	0060	0019
	0014	0052	0059	0075	0112
	0125	0216			
TOSHIBA	0003	0006	0012	0058	0142
US LOGIC	0324				
VIEWSONIC	0399	0251			
VIORE	0300	0388			
VIZIO	0402	0400			
YAMAHA	0251				
ZENITH	0234	0009	0010		

TV/DVD Combos

ACCURIAN	0410				
ADVENT	0511				
AKAI	0386	0417	0445		
APEX DIGITAL	0513	0522			
AUDIOVOX	0418	0420	0421		
AXION	0418				
BROKSONIC	0417				
CINEGO	0521				
CITZEN	0417				
DIAMOND VISION	0525				
DYNEX	0430	0440			
EMERSON	0413	0345	0424		
ESA	0424				
FUNAI	0424				
GFM	0424				
HITACHI	0423				
iLo	0425				
INITIAL	0425				
INSIGNIA	0424	0526	0430		
JENSEN	0511				
KLN	0520				
LG	0350	0426			
MAGNAVOX	0414	0424	0425		
MINTEK	0425				
PANASONIC	0419				
POLAROID	0362	0404	0407	0520	0522
	0526				
PRIMA	0511				
PROSCAN	0447				
RCA	0518	0422	0526	0441	
SAMSUNG	0510				
SANSUI	0417				
SHARP	0258				
SOVA	0421				
SYLVANIA	0413	0345	0416	0424	
TOSHIBA	0363	0382	0417		
TRUTECH	0528				

TV/VCR/DVD Combos

AKAI	0510
BROKSONIC	0512
DIAMOND VISION	0524
EMERSON	0514
ESA	0514
INSIGNIA	0529
MAGNAVOX	0514

PANASONIC	0516	0517			
POLAROID	0523				
RCA	0519				
SYLVANIA	0514				
SYMPHONIC	0514				
TOSHIBA	0515				

TV/VCR

AMERICA ACTION	0235				
AUDIOVOX	0235				
EMERSON	0457				

VCR CODES

VCR

ABS	1159				
ACCENT	1094				
ACCURIAN	1138				
ADELSOUND	1100				
ADMIRAL	1173	1030	1123		
ADVENTURA	1138				
ADYSON	1094	1136			
AGASHI	1094	1137			
AIOSTAY	1100				
AIWA	1138	1041	1050	1035	1134
	1130	1133	1095	1078	1137
AKAI	1052	1053	1054	1087	1071
	1086	1128	1129	1115	1116
	1134	1085			
AKURA	1134	1136	1137		
ALBA	1136	1115	1071	1132	1133
	1094				
ALIENWARE	1159				

ALLORGAN	1127				
ALLSTAR	1082				
AMBASSADOR	1071				
AMSTRAD	1136	1077	1131	1133	
ANITECH	1094	1136	1137		
ANSONIC	1100				
APELSOUND	1100				
ARISTONA(PHILIPS)	1117	1082			
ASA	1095	1117	1082		
ASBERG	1077				
ASHA	1147	1102			
ASUKA	1136	1082	1133	1094	
ATSUI	1100	1099	1133	1127	1131
AUDIO DYNAMIC	1017	1040			
AUDIOSONIC	1094	1071	1136	1137	
AUTHENTIC	1134				
AUTOVOX	1137				
AWA	1137				
BAIRD	1134	1123	1133	1088	1087
BASIC LINE	1094	1071	1136		
BAUER	1135				
BAUR	1137	1098			
BEAULIEU	1137				
BEAUMARK	1147	1102			
BELL & HOWELL	1145	1033	1046		
BELL EXPRESSVU	1158				
BESTAR	1071				
BLAUPUNKT	1089	1090	1118	1120	1117
	1073	1135	1082	1124	
BLUESTAR	1094				
BONDSTEC	1094	1071	1136		
BOSCH	1135				
BRANDT	1134	1125			
BRIONVEGA	1096	1134	1123	1137	
BROKSONIC	1172	1171	1173	1167	1191
	1194	1020	1022	1017	

BRUNS	1094	1071			
BSR	1100				
BUSH	1136	1115	1098	1132	1094
CANON	1012	1011	1135		
CASIO	1116				
CATRON	1071				
CCE	1144				
CGE	1134	1133	1104		
CGM	1071	1123			
CIHAN	1137				
CIMLINE	1136				
CITIZEN	1190	1035			
CLATRONIC	1071				
COLT	1144				
CONDOR	1071				
CONTI	1137				
CRAIG	1143	1147	1144	1018	1035
	1102	1072	1093		
CROWN	1094	1071	1136		
CRYSTAL	1137				
CURTIS MATHES	1161	1146	1163		
CURTIS MATHIS	1007	1041	1012		
CYBERNEX	1147	1102			
CYBERPOWER	1159				
DAEWOO	1190	1044	1015	1012	1064
	1071	1073			
DAIGO	1071				
DANSAI	1094	1095	1136		
DAWA	1137				
DBX	1017	1039	1040		
DE GRAAF	1134	1104	1082	1123	
DECCA	1110	1091	1134	1080	1082
	1133				
DELL	1159				
DENON	1142				
DIGITECH	1094				
DIMENSIA	1007				
DIRECTV	1152	1153			
DISH NETWORK SYSTEM	1158				
DISHPRO	1158				
DIXI	1100				
DOMEOS	1137				
DUAL	1088	1092	1134	1082	1137
	1123	1136			
DUMONT	1133	1117	1082	1123	
DURABRAND	1141	1140			
DUX	1137				
DYNATECH	1138				
DYNATRON	1095				
ECHOSTAR	1158				
EDAN LINE	1123	1136			
EDISON	1094	1136			
ELBE	1095				
ELCATECH	1136				
ELEKTA	1094	1137			
ELIN	1127	1102			
ELSAY	1094	1136			
ELTA	1136	1094			
EMERSON	1172	1138	1171	1168	1173
	1167	1177	1190	1191	1157
	1044	1022			
EMERSON	1023	1019	1020	1021	1041
	1058	1095	1094	1136	1099
ERRES	1095				
ESC	1071	1127			
ESSELTE	1136	1094			
ETZUKO	1136				
EUROMAN	1137				
EUROPHON	1071				
EXPRESSVU	1158				
FENNER	1094	1071	1136		
FERGUSON	1133	1134	1085		

FIDELIS	1137	1071	1093		
FIDELITY	1133	1094	1136		
FILMNET CABLECRYPT	1137				
FINLANDIA	1133	1117	1082	1123	
FINLUX	1091	1137	1113	1087	1093
	1104	1095	1117	1082	1123
	1094				
FIRST LINE	1094	1137	1136		
FISHER	1143	1145	1033	1037	1038
	1036	1093	1104	1123	
FORMENTI-PHOENIX	1095	1137			
FRONTECH	1071				
FUJI	1139				
FUJITECH	1137				
FUJITSU	1133				
FUNAI	1138	1177	1157	1041	1094
	1133				
G.E	1102	1134			
GALAXY	1133				
GALERIA	1094	1071			
GARRARD	1138				
GATEWAY	1159				
GBC	1094	1136			
GE	1161	1147	1162	1163	1164
GEC	1091	1094	1117	1082	1137
GELOSO	1094	1136			
GENERAL ELECTRIC	1032	1007	1012	1062	1094
GENEXXA	1123				
GFM	1157				
GO VIDEO	1175	1148	1051	1042	1043
GODMANS	1094	1071			
GOI	1158				
GOLDHAND	1136				
GOLDMEDAL	1094	1136			
GOLDSTAR	1140	1156			
GOLDSTAR(LG)	1095	1098	1137	1133	1035
GOODMANS	1112	1102	1094	1117	1133
	1122	1136	1082	1127	
GOVIDEO	1175	1148			
GRADIENTE	1138				
GRAETZ	1134	1123	1127		
GRANADA	1137	1135	1117	1082	1123
	1127	1133			
GRANDIN	1094	1133	1136		
GRONIC	1094				
GRUNDIG	1097	1118	1082	1124	1126
	1137	1119	1120	1136	
HANSEATIC	1091	1098	1094	1137	
HARLEY DAVIDSON	1138				
HARMAN/KARDON	1140				
HARWOOD	1144				
HCM	1094	1136	1071		
HEWLETT PACKARD	1159				
HINARI	1100	1134	1136	1094	1099
	1127				
HI-Q	1143				
HITACHI	1138	1142	1170	1011	1007
	1008	1088	1094	1098	1101
	1137				
HMV	1134				
HORNYPHON	1082				
HOWARD COMPUTERS	1159				
HP	1159				
HQ	1015				
HRWOOD	1136				
HTS	1158				
HUGHES NETWORK SYSTEMS		1152	1142	1153	
HUMAX	1152				
HUSH	1159				
HYPER VISION	1094	1136			
HYPSON	1136				
IBUYPOWER	1159				

IMPERIAL	1102	1127	1133		
INGERSOL	1100				
INNO HIT	1102	1094	1136	1127	1137
	1071				
INSTANT REPLAY	1012	1011			
INTERBUY	1094	1136			
INTERFUNK	1091	1103	1117	1082	1123
	1137				
INTERVIDEO	1071				
INTERVISION	1133	1094			
IRRADIO	1095	1094	1072	1136	1082
	1123	1137			
ITT/NOKIA	1086	1088	1103	1104	1105
	1087	1074			
ITV	1071	1137			
JC PENNY	1012	1008	1007	1033	1017
	1039	1040			
JETPOINT	1137				
JOHN PLAYER	1071				
JVC	1169	1192	1158	1017	1047
	1048	1049	1039	1040	1086
	1088	1105			
KAISER	1137				
KAISUI	1094	1136			
KAMBROOK	1137				
KANSAI	1094	1136			
KARCHER	1098	1102	1137		
KENDO	1087	1085	1136	1115	
KENWOOD	1169	1140	1017	1039	1035
	1040	1104	1134		
KIOTA	1116				
KLH	1144				
KORPEL	1136				
KORTING	1137				
KUNYA	1134				
KYOTO	1136				
LAVIS	1094				
LENCO	1094				
LEYCO	1136	1094	1137		
LG	1154				
LG(GOLDSTAR)	1137	1133			
LIESENKOTTER	1137				
LINKSYS	1159				
LLOYD'S	1138				
LOEWE OPTA	1091	1100	1137	1082	1117
LOGIK	1144	1100	1127	1102	1094
	1087	1136			
LUMATRON	1099				
LUXON	1136	1094			
LUXOR	1098	1104	1087	1137	1122
	1136	1123			
LXI(SEARS)	1041	1035	1008	1036	1037
	1033	1038	1052		
M ELECTRONIC	1094				
MAGNADYNE	1137				
MAGNASONIC	1177	1190	1104		
MAGNAVOX	1141	1138	1176	1177	1193
	1013	1011	1012	1010	1063
	1117	1082			
MAGNAVOX	1137				
MAGNIN	1147	1102			
MANESTH	1095	1094	1136	1082	
MARANTZ	1017	1039	1040	1117	1118
	1082	1122			
MARK	1095				
MARQUANT	1094	1136			
MARTA	1035	1095			
MATSUI	1100	1098	1095		
MATSUSHITA	1146	1155			
MAXAM	1094				
MAXELL	1094	1136			
MEDIA CENTER PC	1159				

MEDIATOR 1082
MELECTRONIC 1133
MEMOREX 1146 1141 1143 1147 1138
1145 1173 1154 1155 1156
1189 1012
MEMOREX 1038 1095 1104 1102
MEMPHIS 1094 1136
METZ 1090 1107 1137 1118 1082
1124 1133
MGA 1147 1168
MGN TECHNOLOGY 1147 1102
MICROSOFT 1159
MIGROS 1133 1136
MIND 1159
MINERVA 1090 1120 1124
MINOLTA 1142 1008 1007 1134
MITSUBISHI 1169 1168 1162
MITSUBISHI/MGA 1026 1027 1028 1029 1056
1057 1065 1059 1094 1106
MTC 1147 1138 1102
MULTITECH 1138 1144 1028 1041 1024
1094 1071
MURPHY 1133
NEC 1145 1169 1140 1017 1039
1040 1088 1134 1080
NECKERMANN 1086 1088 1091 1098 1099
1102 1104 1137 1134
NECOLA 1071
NEI 1095
NESCO 1136 1099
NEWTECH 1137
NIKKAI 1071 1136
NIVEUS MEDIA 1159
NOBLEX 1147 1102
NOKIA 1134 1104 1137 1082 1123
1087 1127
NORDMENDE 1086 1088 1092 1105 1108
1109 1134 1070
NORTHGATE 1159
NTC 1102
OCEANIC(ITT) 1134 1104 1082 1123 1087
1133 1137
OKANO 1094 1071 1136 1115
OLYMPIC 1012 1011 1071
OLYMPUS 1135
ONCEAS 1071
OPTIMUS 1183 1146 1145 1175 1177
1182 1155 1189 1027
ORAA 1137
ORAVA/OTF 1137
ORION 1172 1173 1167 1191 1055
1099 1100 1132
ORSON 1133
ORVICA 1071
OSAKI 1095 1094 1136 1133
OTAKE 1132
OTF 1137
OTTO VERSAND 1091 1098 1137 1082 1117
OVP 1137
PACIFIC 1082 1136
PADIOTONE 1137
PALLADIUM 1087 1100 1134 1136 1127
1115
PANAMA 1137
PANASONIC 1183 1146 174 1148 1149
1163 1155 1189 1009 1010
1011 1012
PANASONIC 1060 1071 1089 1103
PATHE CINEMA 1100 1134
PATHE MARCONI 1134
PENNEY 1147 1142 1140 1163 1156
1102

PENTAX	1142	1008	1007	1101	
PERDIO	1133				
PHILCO	1011	1012	1044	1020	1136
	1094				
PHILIPS	1152	1150	1184	1187	1035
	1013	1011	1012	1063	1091
	1113				
PHONOLA	1117	1082	1091		
PILOT	1095				
PIONEER	1169	1011	1091		
PORTLAND	1071				
PRESIDIAN	1157				
PRINZ	1133				
PROFESSOR	1137				
PROFEX	1094	1136			
PROFITRONIC	1147	1082	1127	1102	
PROLINE	1136	1133			
PROSCAN	1161	1164			
PROSONIC	1137				
PROTEC	1144				
PROTECH	1137				
PULSAR	1141				
PYE	1117	1082			
QUARTA	1104				
QUARTZ	1104				
QUASAR	1146	1163	1155	1011	1012
	1009	1010	1006		
QUELLE	1090	1091	1099	1110	1137
	1102	1095	1135	1117	1082
QUESTAR	1071				
RADIOLA	1117	1082			
RADIOSHACK	1138	1154			
RCA	1161	1147	1142	1162	1165
	1163	1164			
RCA/PROSCAN	1007	1008	1011	1012	1013
	1014	1015	1016		

REALISTIC	1143	1138	1145	1012	1033
	1031	1038	1027	1041	1102
	1104	1095			
REFLEX	1137				
REPLAYTV	1148	1149			
REVOX	1075				
REX	1088	1105	1134		
RFT	1117	1136	1094		
RICAVISION	1159				
RICOH	1111				
ROADSTAR	1094	1136	1127		
ROYAL	1094	1071	1136		
RUNCO	1141				
SABA	1086	1088	1092	1105	1134
	1125	1126			
SAISHO	1099	1100			
SALORA	1123	1087	1137	1098	1104
SAMSUNG	1152	1147	1180	1025	1016
	1024	102	1085	1127	
SAMURAI	1071				
SANKY	1141				
SANSUI	1138	1169	1173	1191	1017
	1072	1094	1116	1134	1080
	1087				
SANWA	1100				
SANYO	1143	1147	1145	1033	1038
	1046	1044	1035	1104	1123
	1070	1079			
SANYO	1025				
SAVILLE	1127				
SBR	1082				
SCHAUB LORENZ	1134	1123	1087	1133	1137
SCHNEIDER	1091	1094	1102	1082	1095
	1136	1133	1137		
SCOTT	1172	1171	1168	1015	1016
	1024	1038	1026	1027	1028

	1029				
SEARS	1143	1138	1142	1145	1156
SEG	1094	1088	1102	1136	1127
	1137				
SEI-SINUDYNE	1117	1100	1082		
SELECO	1137	1134	1071	1115	
SENTRA	1094	1071	1136		
SENTRON	1136				
SHARP	1162	1179	1030	1031	1112
	1122				
SHINCO	1094	1136			
SHINTOM	1144	1018	1136	1123	1094
SHOGUN	1147	1102			
SHORAI	1100				
SIEMENS	1124	1090	1104	1117	1118
	1119	1120	1082	1123	
SIERRA	1082				
SIGNATURE 2000	1041	1030			
SILMA	1137				
SILVA	1071				
SINGER	1144	1018			
SINUDYNE	1100	1082	1091	1137	
SOLAVOX	1071				
SONIC BLUE	1148	1149			
SONNECLAIR	1136				
SONOKO	1123	1136	1071		
SONOLOR	1104				
SONY	1188	1139	1138	1151	1181
	1159	1110	1111	1121	1087
	1001				
SONYCS	1136				
SPECIAL	1095				
SSANGYONG	1136				
STACK 9	1159				
STANDARD COMP	1071	1137			
STARLITE	1123				
STRONG	1094				
STS	1142				
SUNPAK	1111				
SUNSTAR	1133				
SUNWOOD	1136				
SUPERTECH	1137				
SUPRA	1094	1127			
SYLVANIA	1138	1168	1177	1157	1193
	1013	1011	1012	1041	
SYMPHONIC	1138	1177	1157	1041	1136
	1133				
SYSTEMAX	1159				
TAGAR SYSTEMS	1159				
TAISHO	1100				
TANDBERG	1099				
TASHIKO	1094	1035	1082	1127	1133
	1136				
TATUNG	1017	1039	1040	1091	1085
	1133	1082			
TEAC	1138	1017	1039	1041	1040
	1134				
TEC	1094	1071	1104	1136	
TECHLINE	1094	1136			
TECHNICS	1146	1012	1011	1083	
TEF	1134				
TEKNANT	1095	1137			
TEKNIKA	1138				
TELEAVIA	1134				
TELEFUNKEN	1086	1088	1092	1105	1134
	1102				
TELERENT	1094	1071	1134		
TELETECH	1094	1136			
TELEVIDEON	1071	1104			
TELKOM	1137				
TENOSAL	1094	1136			
TENSAI	1094	1100	1102	1136	1137

	1133				
TESLA	1137				
THOMAS	1138				
THOMSON	1086	1088	1092	1105	1134
	1125	1076			
THORN FERGUSON	1135	1136	1099	1088	1100
	1137	1086			
TIVO	1152	1150	1151	1153	1160
TMK	1147	1099	1102		
TOKAI	1137	1134	1136	1123	1094
TONSAI	1094				
TOSHIBA	1168	1178	1166	1186	1159
	1160	1015	1014	1052	1088
	1105	1114			
TOSHIBA	1134	1081			
TOTEVISION	1147	1102	1095		
TOUCH	1159				
TOWADA	1094	1136	1116		
TRANSONIC	1137				
TTR	1134				
TVA	1071				
TWINNER	1094				
UHER	1071	1127	1134	1102	1100
	1088				
UNIC RADIO	1094				
UNITECH	1147	1102	1127		
UNIVERSUM	1124	1127	1077	1094	087
UNIVIDEO	1071				
VECTOR RESEARCH	1140				
VICTOR	1080	1134	1088		
VIDAR	1104				
VIDEO ELECTRONIC	1136				
VIDEO TECHNIK	1094				
VIDEOMASTER	1071				
VIDEOSONIC	1147	1102			
VIDION	1123	1136			
VIEWSONIC	1159				
VILLAIN	1138				
VOODOO	1159				
WARDS	1161	1143	1147	1138	1142
	1144	1030	1031	1038	1034
	1035				
WATSON	1082	1137			
WELTBLICK	1095				
WHITE WESTINGHOUSE	1173	1144	1136	1095	1104
	1123				
XENON	1099				
XR-1000	1138	1144			
YAMAHA	1140	1033	1017	1039	1040
YAMASHI	1136				
YOKAN	1136				
YOKO	1102	1095	1094	1136	1127
	1071				
YOSHITA	1094				
ZANELA	1094	1104			
ZENITH	1141	1139	1138	1173	1185
	1191	1034			
ZT GROUP	1159				

DVRS

ABS	1159				
ALIENWARE	1159				
BELL EXPRESSVU	1158				
CYBERPOWER	1159				
DELL	1159				
DIRECTV	1152	1153			
DISH NETWORK SYSTEM	1158				
DISHPRO	1158				
ECHOSTAR	1158				
EXPRESSVU	1158				
GATEWAY	1159				

GO VIDEO	1148			
GOI	1158			
HEWLETT PACKARD	1159			
HOWARD COMPUTERS	1159			
HP	1159			
HTS	1158			
HUGHES NETWORK SYSTEMS		1152	1153	
HUMAX	1152			
HUSH	1159			
IBUYPOWER	1159			
JVC	1158			
LINKSYS	1159			
MEDIA CENTER PC	1159			
MICROSOFT	1159			
MIND	1159			
NIVEUS MEDIA	1159			
NORTHGATE	1159			
PANASONIC	1148	1149		
PHILIPS	1152	1150		
RCA	1165			
REPLAYTV	1148	1149		
SAMSUNG	1152			
SONIC BLUE	1148	1149		
SONY	1151	1159		
STACK 9	1159			
SYSTEMAX	1159			
TAGAR SYSTEMS	1159			
TIVO	1152	1150	1151	1153
TOSHIBA	1166	1159	1160	
TOUCH	1159			
VIEWSONIC	1159			
VOODOO	1159			
ZT GROUP	1159			

TV/VCR

BROKSONIC	1167	1191			
CITIZEN	1190				
COLT	1144				
CURTIS MATHES	1163				
DAEWOO	1190				
EMERSON	1167	1177	1190	1191	
FUNAI	1138				
GE	1147	1162	1163	1164	
GOLDSTAR	1156				
HARLEY DAVIDSON	1138				
HITACHI	1138				
LG	1154				
LLOYD'S	1138				
MAGNASONIC	1177	1190			
MAGNAVOX	1138	1177	1193		
MAGNIN	1147				
MEMOREX	1146	1154	1155	1156	1189
MGA	1147				
MITSUBISHI	1162				
OPTIMUS	1146	1177	1155	1189	
ORION	1167	1191			
PANASONIC	1146	1163	1155	1189	
PENNEY	1147	1163	1156		
QUASAR	1146	1163	1155		
RADIOSHACK	1138	1154			
RCA	1147	1162	1163	1164	
SAMSUNG	1180				
SANSUI	1138	1191			
SANYO	1147				
SEARS	1138	1156			
SONY	1188	1138			
SYLVANIA	1193				
SYMPHONIC	1138	1177			
THOMAS	1138				
TOSHIBA	1178	1186			
ZENITH	1138	1191			

TV/VCR.DVD

SHARP	1162

DVD CODES

DVD

ACCURIAN	2161	2238			
ADVENT	2188				
AFREEY	2065				
AIWA	2299	2015	2061	2083	
AKAI	2162	2169	2326	2334	2117
ALBA	2093	2094	2095		
ALCO	2172				
ALLEGRO	2183				
AMES	2132				
AMPHION MEDIA WORKS	2184	2221			
AMW	2184	2221			
APEX	2121	2125			
APEX DIGITAL	2159	2166	2310	2315	2316
	2317	2321	2327	2193	2195
	2335	2251			
ARRGO	2189				
ASPIRE DIGITAL	2216	2237			
ASTAR	2253	2265			
AUDIOSONIC	2080				
AUDIOVOX	2172	2209	2210		
B&K	2157				
BBK	2219				
BEL CANTO DESIGN	2259				
BLAUPUNKT	2166				
BLUE PARADE	2151				
BOSE	2271				
BROKSONIC	2162	2182	2239		
BUFFALO	2269				
BUSH	2093	2094	2095		
CENTRIOS	2260				
CINEA	2177				
CINEVISION	2185	2178	2183		
CITIZEN	2162	2228			
CLASSIC	2132				
CMWELL	2069				
COBY	2170	2180	2203	2207	2215
	2218	2234			
CRAIG	2177				
CURTIS MATHES	2204				
CYBERHOME	2319	2325	2189	2329	2208
	2212	2254	2359	2065	
DAEWOO	2313	2303	2178	2183	2340
	2341	2344	2345	2352	2245
	2029	2097			
DAEWOO	2112	2113			
DANSAI	2094				
DENON	2146	2298	2377	2006	2017
	2050	2131			
DESAY	2237				
DIAMOND VISION	2230	2262	2263		
DIGITALMAX	2267				
DISNEY	2161	2225			
D-LINK	2268				
DUAL	2197	2202			
DURABAND	2211	2274			
DVD2000	2148				
D-VISION	2217				
ELTA	2115	2120			
EMERSON	2153	2161	2176	2224	
EMTERPRISE	2153				
ESA	2176	2224	2245		
FISHER	2158	2270			
FUNAI	2161	2224	2231		

GATEWAY	2199	2201	2213			KONKA	2304	2306	2307	2129	2130
GE	2149	2175	2166				2135	2102	2103		
GFM	2161	2224				KOSS	2156	2186	2240		
GO VIDEO	2308	2305	2167	2312	2178	LASONIC	2318	2217	2116		
	2183	2331	2333	2205	2337	LENCO	2072				
	2213	2229				LENOXX	2211				
GO VIDEO	2245	2266	2122			LG	2153	2167	2183	2258	
GOLDSTAR	2167					LITEON	2194	2213	2238	2244	2264
GOODMANS	2093	2094	2095				2267				
GPX	2163	2168				LOEWE	2286				
GREENHILL	2166					LOEWE OPTA	2051	2058			
GRUNDIG	2051					LUXMAN	2056				
HARMAN/KARDON	2292	2164	2343	2018	2092	MAGNAVOX	2147	2150	2155	2161	2176
HELIOS	2276						2224	2350	2249	2256	2099
HELLO KITTY	2177						2104				
HITACHI	2291	2300	2346	2270	2008	MAKAMICHI	2075				
	2054	2055	2056			MALATA	2171				
HITEKER	2159					MARANTZ	2150	2380	2087	2058	
HUMAX	2261					MCLNTOSH	2226				
ILO	2233	2249				MEMOREX	2162	2177	2225	2277	
INITIAL	2166	2249				MICROSOFT	2149	2272			
INSIGNIA	2161	2224	2273	2282		MINTEK	2179	2166	2249		
INTEGRA	2294	2365	2374	2133		MITSUBISHI	2357	2148	2100	2084	2114
IRRADIO	2053					MUSTEK	2132				
JBL	2164					NAD	2167	2076	2136		
JENSEN	2188					NAKAMICHI	2134				
JSI	2240					NEC	2314				
JVC	2290	2293	2323	2214	2227	NESA	2166				
	2361	2362	2367	2007	2037	NEXXTECH	2236				
	2052	2089				NORCENT	2187	2184	2207	2223	2246
JVC	2126					OLEVIA	2280				
JWIN	2192					ONKYO	2147	2294	2365	2373	2374
KAWASAKI	2172						2016	2060	2133		
KENWOOD	2146	2288	2301	2079	2086	OPPO	2152	2219	2275		
KITEKER	2063	2066				OPTOMEDIA ELECTRONICS	2186				
KLH	2166	2172	2338	2222	2010	ORITRON	2156	2118			

OTHERS	2139	2140	2141	2142	2143
	2144				
PANASONIC	2146	2296	2165	2351	2353
	2354	2363	2364	2002	2006
	2027	2028			
PANASONIC	2034	2035	2036	2042	2045
PHILCO	2161				
PHILIPS	2147	2150	2371	2155	2161
	2322	2348	2349	2232	2350
	2372	2379			
PHILIPS	2381	2012	2087	2051	2058
	2099	2104			
PIONEER	2287	2151	2284	2154	2296
	2247	2259	2382	2004	2019
	2021	2033			
PIONEER	2054	2081	2085	2090	2101
POLAROID	2195	2203	2221	2222	2230
	2250	2251	2252	2279	
POLK AUDIO	2150				
PORTLAND	2169				
PRESIDIAN	2161	2267			
PRIMA	2188				
PRIMARE	2248				
PRINCETON	2160				
PROFILO	2093	2095			
PROLINE	2093	2095			
PROSCAN	2149				
PROVISION	2170				
QWESTAR	2156				
RADIOSHACK	2109	2137	2138		
RAITE	2077				
RCA	2149	2151	2166	2172	2320
	2328	2336	2342	2365	
RCA/PROSCAN	2005	2109	2111	2137	2138
REVOX	2051	2072			
RIO	2183				
RJTECH	2235				
ROADSTAR	2070				
ROTEL	2293	2052			
SAMPO	2302	2309	2355	2123	
SAMSUNG	2146	2291	2285	2326	2331
	2333	2378	2014	2041	2056
	2091	2098			
SANSUI	2162				
SANYO	2158	2162	2324	2270	2105
SAV	2181	2206			
SCHAUB LORENZ	2051				
SCHMARTZ	2281				
SEG	2065	2127			
SENSORY SCIENCE	2213				
SHARP	2295	2161	2309	2347	2376
	2011	2048			
SHARPER IMAGE	2208				
SHERWOOD	2297	2169	2330	2201	2368
	2119				
SHERWOOD NEWCASTLE	2201				
SHINCO	2022	2111			
SHINSONIC	2145	2179			
SIGMA DESIGNS	2160				
SINUDYNE	2059				
SKYWORTH	2068	2082	2096		
SONIC BLUE	2183	2205			
SONY	2145	2358	2283	2311	2191
	2198	2241	2242	2243	2356
	2360	2369			
SONY	2370	2001	2023	2024	2025
	2030	2031	2032	2040	2078
SOVA	2210				
SUNGALE	2200				
SUPERSCAN	2176				
SAV	2181	2206			
SYLVANIA	2161	2176	2224	2375	2020

	2044	2049			
SYMPHONIC	2161	2176			
TEAC	2172	2054			
TECHNICS	2146	2165			
TERAPIN	2190				
THETA DIGITAL	2151	2090			
THOMSON	2013	2057			
TIVO	2255				
TOSHIBA	2147	2162	2332	2339	2255
	2257	2261	2365	2366	2278
	2003	2038			
TOSHIBA	2039	2046	2106	2124	2108
	2009	2041	2047	2098	2107
	2122				
TREDEX	2173	2174			
UNK	2062				
URBAN CONCEPTS	2147				
US LOGIC	2179				
VENTURER	2172				
VIZIO	2196	2220			
VOCOPRO	2235				
WMM NETSTATION	2071	2073	2074		
XBOX	2149	2272			
YAMAHA	2146	2150	2289	2006	2064
	2088	2110			
YAMAKAWA	2128				
ZENITH	2147	2153	2167	2183	2009
	2047	2107			
ZOECE	2223				

DVD-R

ACCURIAN	2161	2238			
APEX DIGITAL	2193				
ASPIRE DIGITAL	2216				
ASTAR	2253				
BROKSONIC	2239				
COBY	2203				
CYBERHOME	2212	2254			
DIGITALMAX	2267				
FUNAI	2161	2231			
GATEWAY	2199	2213			
GO VIDEO	2167	2213	2229	2266	
HUMAX	2261				
ILO	2233				
JVC	2214	2227			
LG	2167				
LITEON	2213	2238	2244	2267	
MAGNAVOX	2155	2161	2256	2099	2104
PANASONIC	2146	2002	2006	2027	2028
	2034	2035	2036	2042	2045
PHILIPS	2155	2232	2012	2087	2051
	2058	2099	2104		
PIONEER	2154	2247	2004	2019	2021
	2033	2054	2081	2085	2090
	2101				
POLAROID	2203				
PRESIDIAN	2267				
RCA	2149				
SAMSUNG	2146	2014	2041	2056	2091
	2098				
SANYO	2158	2105			
SENSORY SCIENCE	2213				
SHARP	2161	2011	2048		
SONY	2191	2198	2241	2242	2243
	2001	2023	2024	2025	2030
	2031	2032			
SONY	2040	2078			
SYLVANIA	2161	2020	2044	2049	
TOSHIBA	2257	2261	2278		
ZENITH	2167	2009	2047	2107	

TV/DVD Combos

ADVENT	2188		
AKAI	2162		
APEX DIGITAL	2321	2251	
AUDIOVOX	2209	2210	
BROKSONIC	2162		
CITIZEN	2162		
DIAMOND VISION	2263		
EMERSON	2161	2224	
ESA	2224		
FUNAI	2224		
GFM	2224		
HITACH	2346		
ILO	2249		
INITIAL	2249		
INSIGNIA	2224		
JENSEN	2188		
KLN	2222		
KONKA	2306	2307	
LG	2258		
MAGNAVOX	2224	2249	
MINTEK	2249		
PANSONIC	2354		
PHILIPS	2322	2348	
POLAROID	2222	2251	
PRIMA	2188		
RCA	2328	2342	
SAMSUNG	2326		
SANSUI	2162		
SOVA	2210		
SYLVANIA	2161	2224	2375
TOSHIBA	2162		

TV/VCR/DVD Combos

AKAI	2326		
BROKSONIC	2182		
DIAMOND VISION	2262		
EMERSON	2176		
ESA	2176		
FUNAI	2231		
MAGNAVOX	2176		
PANASONIC	2351	2353	
POLAROID	2252		
RCA	2336		
SHARP	2295		
SUPERSCAN	2176		
SYLVANIA	2176		
SYMPHOMIC	2176		
TOSHIBA	2332		

Blu-ray DVD Disc/HD-DVD player

DENON	2392		
INSIGNIA	2385	2396	2404
INTEGRA	2390		
LG	2386		
MAGNAVOX	2385		
MARANTZ	2395	2397	
NAD	2403		
OLEVIA	2394		
ONKYO	2390		
OPPO	2400		
PANASONIC	2388		
PHILIPS	2389	2398	
PIONEER	2383	2399	
SAMSUNG	2384		
SHARP	2391		
SONY	2387		
SYLVANIA	2385		
VIORE	2401		

VIZIO	2402				
YAMAHA	2393				
ONE	2406	2405			
JNC	2407				

AUDIO CODES

Amplifier

DURABRAND	3430				
HARMAN/KARDON	3366				
JVC	3350				
LEFT COAST	3366				
LENOXX	3430				
MARANTZ	3366				
OPTIMUS	3361				
PHILIPS	3366				
PIONEER	3361				
POLK AUDIO	3366				
RCA	3361				
SONY	3359				
VICTOR	3350				
YAMAHA	3351				

Receiver

ACCURIAN	3469				
AIWA	3411	3348	3344	3379	3437
	3022	3023	3040	3079	
AKAI	3421				
ALCO	3409				
ANAM	3433	3369			
APEX DIGITAL	3384	3414	3446		
AUDIOTRONIC	3377				
AUDIOVOX	3409				
B&K	3358	3360	3362		

BOSE	3378	3357	3382	3435	3457
	3465				
CAMBRIDGE SOUNDWORKS	3404	3478			
CARVER	3377	3348			
DAEWOO	3380				
DENON	3402	3374	3477	3481	3010
	3024	3027	3028	3036	3037
	3110				
FISHER	3449	3011			
GATEWAY	3423				
GO VIDEO	3427				
HARMAN/KARDON	3348	3365	3395	3396	3476
	3035				
HITACHI	3449				
INSIGNIA	3368	3370	3463	3471	3473
INTEGRA	3345	3394	3400	3450	
JBL	3396				
JVC	3405	3441	3461	3475	3480
	3019	3020	3047	3070	3078
	3098				
KENWOOD	3398	3432	3431	3347	3015
	3016	3025	3071	3082	3083
KLH	3409	3412	3413		
KOSS	3403				
LENCO	3113	3114	3115	3116	3117
	3118	3119			
LG	3392	3474			
LINN	3348				
MAGNAVOX	3377	3387	3348	3354	3422
	3021				
MARANTZ	3377	3387	3348	3391	3029
	3094	3044			
MITSUBISHI	3410				
NAD	3103	3033			
NAKAMICHI	3104	3087	3086		
ONKYO	3345	3363	3394	3400	3426

	3450	3034	3039	3043	3084
OPTIMUS	3367	3347	3369		
ORITRON	3403				
PANASONIC	3397	3352	3390	3399	3428
	3436	3444	3445	3482	3008
	3077	3099			
PHILIPS	3377	3387	3348	3354	3386
	3456	3479	3106	3107	3108
	3111	3112			
PHILIPS	3017				
PIONEER	3367	3349	3356	3373	3408
	3466	3018	3032	3072	3081
	3085	3090			
PIONEER	3006				
POLAROID	3419				
POLK AUDIO	3348	3391			
PROSCAN	3383				
RCA	3367	3433	3383	3369	3373
	3409	3420	3467	3105	3091
	3092	3093			
RIO	3460				
ROTEL	3067	3115			
SAMSUNG	3393	3418	3459		
SANSUI	3348	3086	3087	3089	3038
SANYO	3381	3416	3449	3011	
SHARP	3347	3389	3028	3037	3080
	3100				
SHERWOOD	3370	3423	3439	3464	3471
	3012	3013	3031		
SHERWOOD NEWCASTLE	3471				
SONIC BLUE	3427	3460			
SONY	3443	3343	3415	3385	3434
	3429	3440	3442	3454	3458
	3472	3120			
SONY	3001	3002	3109		
STEREOPHONICS	3367				
SUNFIRE	3398				
TEAC	3369	3409	3425	3088	
TECHNICS	3397	3007	3026	3045	3073
THORENS	3377				
TOSHIBA	3448	3101			
VENTURER	3409				
VIZIO	3423				
WARDS	3348				
YAMAHA	3346	3347	3353	3376	3388
	3401	3406	3407	3417	3453
	3468	046			
YAMAHA	3102	3014	3030		
ZENITH	3364	3392			

Audio Accessories

ACCURIAN	3371				
ALTEC LANSING	3355				
APPLE	3372	3438			
D-LINK	3424				
DLO	3375				
GXP	3470				
GRIFFIN	3462				
IDECK	3371				
ILIVE	3470				
MONITOR AUDIO	3371				
NAVIPOD	3438				
NETGEAR	3447				
ROKU	3455				
SSI	3424				
YAMAHA	3451	3452			

CD

AIWA	3141	3142	3157	3193	
DENON	3128	3129	3143	3146	

EMERSON	3210				
FISHER	3160				
GOLDSTAR/LG	3217	3127			
HARMAN/KARDON	3151				
HITACHI	3161				
JVC	3138	3139	3153	3192	
KENWOOD	3134	3135	3144	3154	3184
	3196	3197			
MAGNAVOX	3136	3146			
MARANTZ	3190				
NAD	3149				
NAKAMICHI	3164	3201			
ONKYO	3150	3155	3158	3198	
PANASONIC	3126	3191	3213		
PHILIPS	3136				
PIONEER	3124	3137	3148	3185	3195
RCA	3199	3200	3207	3208	
SANSUI	3201	3202	3205		
SANYO	3130				
SHARP	3194	3214			
SHERWOOD	3131	3132	3159		
SONY	3121	3122	3218	3219	3220
TECHNICS	3125	3145	3152	3186	
YAMAHA	3133	3147	3156		

MD/DAT

AIWA	3300				
AKAI	3306				
DENON	3291				
JVC	3293	3296			
KENWOOD	3292	3299	3302		
MARANTZ	3295				
ONKYO	3308(DAT)				
PANASONIC	3298	3294			
PIONEER	3304	3308(DAT)			

SANSUI	3297				
SHARP	3301				
SONY	3289	3290	3307(DAT)		
TEAC	3293				
YAMAHA	3305				

HIFI

FISHER	3310				
HITACHI	3311				
INKEI	3321				
KENWOOD	3309	3312	3313	3314	3315
LENCO	3329	3330	3331	3332	3333
ONKYO	3316	3317			
PANASONIC	3318				
PHILIPS	3328				
PIONEER	3325	3334	3338		
SANYO	3319				
SHARP	3312				
SHERWOOD	3320	3321	3326	3327	
SONY	3335				
TECHNICS	3322				
YAMAHA	3323	3324			

LD

DENON	3338	
KENWOOD	3339	
MAGNAVOX	3338	
PANASONIC	3340	3341
PHILIPS	3336	
SONY	3342	
TOSHIBA	3338	
ZENITH	3337	

TAPE

AIWA	3249	3251	3239	3284	
DENON	3241	3227	3228		
FISHER	3229				
GOLDSTAR/LG	3226				
HARMAN/KARDON	3244				
JVC	3237	3238			
KENWOOD	3246	3233			
MARANTZ	3253				
NAD	3243				
NAKAMICHI	3279	3287			
ONKYO	3247	3248	3250		
PANASONIC	3268				
PHILIPS	3253	3268			
PIONEER	3245	3236	3224		
RCA	3282	3283			
ROTEL	3288				
SANSUI	3279	3278			
SANYO	3229				
SHARP	3241	3285			
SONY	3221	3222	3223		
TEAC	3278	3280			
TECHNICS	3252	3225	3268		
YAMAHA	3242	3232			

CBL CODES

CABLE

ABC	4068	4003	4010	4002	4004
	4031	4032	4016		
AMERICAST	4077				
AMINO	4084	4085			
BELL & HOWELL	4002				
BELL SOUTH	4077				
BIRMINGHAM CABLE	4001	4059	4074		
BRIGHT HOUSE	4083	4086			
BRITISH TELECOM	4003	4032			
CABLE ONE	4083	4086			
CABLEVISION	4083	4086			
CHARTER	4083	4086	4088		
CISCO	4086	4081	4087		
COGECO	4080	4081	4082	4083	4086
COLOUR VOICE	4039	4040			
COMCAST	4083	4086	4087	4090	
COMTRONICS	4038				
CONTEC	4028				
COX	4083	4086			
DECSAT CANAL+	4127				
DIGEO	4082	4088			
DIRECTOR	4080	4074			
EVERQUEST	4008	4038			
FRANCE TELECOM	4154	4170			
GEMINI	4008				
GENERAL INSTRUMENT	4080	4074	4001	4004	4059
GOLDSTAR	4014	4038			
HAMLIN	4023	4026	4024	4071	
HAMLIN/REGAL	4071				
HITACHI	4004				
HOMECAST	4089				
I3 MICRO	4084				
INSIGHT	4083	4086			
JASCO	4008				
JERROLD	4080	4003	4059	4017	4001
	4002	4008	4004	4006	4032
	4007	4074			
JERROLD/G.I	4074				
MEDIACOM	4083	4086			
MEMOREX	4067	4012			
MOTOROLA	4083	4080	4082	0474	
MYRIO	4084	4085			
OAK	4028				

PACE	4086	4070			
PANASONIC	4087	4067	4069	4012	
PARAGON	4067	4012			
PHILIPS	4072	4073	4039	4040	
PIONEER	4086	4081	4076	4075	4079
	4014	4015	4011	4058	4281
PULSAR	4067	4012			
PVP STEREO VISUAL MATRIX	4003	4032			
QUASAR	4067	4012			
RADIOSHACK	4008				
REGAL	4071	4023	4024		
REMBRANDT	4004				
ROGERS	4080	4081	4082	4083	4086
RUNCO	4067	4012			
SAGEM	4389				
SAMSUNG	4014	4038			
SCIENTIFIC ATLANTA	4086	4081	4076	4068	4079
	4010	4011	4058	4281	
SEJIN	4084				
SHAW	4080	4081	4082	4083	4086
SIGNAL	4008	4038			
SIGNATURE	4004				
SL MARX	4038				
SONY	4078				
STARCOM	4003	4008	4032		
STARGATE	4008	4038			
STARQUEST	4008				
SUDDENLINK	4083	4086			
SUPERCABLE	4074				
TELEVIEW	4038				
TIME WWRNER	4083	4086	4088		
TIVO	4090				
TOCOM	4017	4031	4016		
TOSHIBA	4067	4012			
TUSA	4008				
UNITED CABLE	4003	4032			
ZENITH	4077	4067	4012		

CBL/ANALONG

HAMLIN/REGAL	4022	4023	4024	4025	4026
	4071				
JERROLD/G.I	4031	4001	4002	4003	4004
	4005	4006	4007	4008	4018
	4022	4032			
JERROLD/G.I	4074				
OAK	4027	4028	4029		
PANASONIC	4019	4020	4021	4067	4069
	4012				
PIONEER	4014	4015	4076	4075	4079
	4011	4058	4281		
SCIENTIFIC ATLANTA	4009	4010	4011	4076	4068
	4079	4058	4281		
TOCOM	4031	4016	4017		
ZENITH	4012	4013	4077	4067	

CBL/DIGITAL

JERROLD/G.I.	4015				
MOTOROLA	4015	4074			
PANASONIC	4021	4067	4069	4012	
PHILIPS	4016	4072	4073	4039	4040
SCIENTIFIC ATLANTA	4014	4076	4068	4079	4010
	4011	4058	4281		
SONY	4013	4078			

DVR-COMBOS

AMINO	4085	
BRIGHT HOUSE	4083	4086
CABLE ONE	4083	4086
CABLEVISION	4083	4086

CHARTER	4083	4086	4088		
CISCO	4086	4087			
COMCAST	4083	4086	4087	4090	
COX	4083	4086			
DIGEO	4082	4088			
HOMECAST	4089				
INSIGHT	4083	4086			
MEDIACOM	4083	4086			
MOTOROLA	4083	4082	4074		
MYRIO	4085				
PACE	4086	4070			
PANASONIC	4087	4067	4069	4012	
PIONEER	4086	4076	4075	4079	4014
	4015	4011	4058	4281	
SCIENTIFIC ATLANTA	4086	4076	4068	4079	4010
	4011	4058	4281		
SUDDENLINK	4083	4086			
TIME WWRNER	4083	4086	4088		
TIVO	4090				

DTV

ACCESS HD	4482
AIRLINDK 101	4112
ALPHA DIGITAL	4482
AMTC	4482
APEX DIGITAL	4105
ARTEC	4111
CASTI	4484
CHANNEL MASTER	4489
COSHIP	4108
DAEWOO	4486
DAYTEK	4484
DIGITAL STREAM	4483
DISH NETWORK SYSTEM	4104
ECHOSTAR	4104

EVOLUTION	4106			
GE	4488	4490		
GOODMIND	4490			
GRIDLINK	4487			
INSIGNIA	4480			
LASONIC	4487			
MAGNAVOX	4481			
MEMOREX	4107			
MICROGEM	4110			
PHILCO	4481			
RCA	4485	4103		
SANSONIC	4487			
SYLVANIA	4481			
TIVAX	4482			
VENTURA	4103			
VENTURER	4103			
WINEGARD	4103			
ZENITH	4480	4077	4067	4012
ZENTECH	4112			
ZINWELL	4109			

VIDEO

ABS	4092	
ACCESS HD	4482	
ADB	4096	4113
AIRLINK 101	4112	
ALIENWARE	4092	
ALPHA DIGITAL	4482	
AMINO	4094	4102
AMTC	4482	
APEX DIGITAL	4105	
ARTEC	4111	
AT&T	4091	
CASTI	4484	
CHANNEL MASTER	4489	

CISCO	4099								
COSHIP	4108								
CYBERPOWER	4092								
DAEWOO	4486								
DAYTEK	4484								
DIGITAL STREAM	4483								
DISH NETWORK SYSTEM	4104								
ECHOSTAR	4104								
ENTONE	4098								
EPSON	4481								
EVOLUTION	4106								
GATEWAY	4092								
GE	4488	4490							
GOODMIND	4490								
GRIKLINK	4487								
HEWLETT PACKARD	4092								
HOWARD COMPUTERS	4092								
HP	4092								
HUSH	4092								
IBUYPOWER	4092								
INSIGNIA	4480								
KOOICONNECT	4094								
LASONIC	4487								
LG	4480								
LINKSYS	4092								
MAGNAVOX	4481								
MEDIA CENTER PC	4092								
MEMOREX	4107								
MICROGEM	4110								
MICROSOFT	4092								
MIND	4092								
MOTOROLA	4095	4091	4101						
NIVEUS MEDIA	4092								
NORTHGATE	4092								
PHILCO	4481								
RCA	4485	4103							
RICAVISION	4092								
ROKU	4100								
SANSONIC	4487								
SCIENTIFIC ATLANTA	4091	4099							
SONY	4092	4093							
STACK 9	4092								
SUREWEST	4094								
SYLVANIA	4481								
SYSTEMAX	4092								
TAGAR SYSTEMS	4092								
TIVAX	4482								
TOSHIBA	4092								
TOUCH	4092								
VENTURA	4103								
VENTURER	4103								
VERIZON	4101								
VIEWSONIC	4092								
VOODOO	4092								
VUDU	4097								
WINEGARD	4103								
ZENITH	4480								
ZENTECH	4112								
ZINWELL	4109								
ZT GROUP	4092								

SAT CODES

SAT

@SAT	4367								
ABSAT	4295	4138	4128	4143					
AKAI	4172								
ALBA	4311	4313	4167	4172	4181				
ALDES	4302	4145	4153						
ALLANTIDE	4221								
ALLSONIC	4283								

ALPHASTAR	4438				
ALSES	4283				
AMSTRAD	4314	4133	4158	4234	4253
	4390				
ANKARO	4302	4328	4306	4145	4275
	4153				
ANTTRON	4311	4167			
ARCON	4339				
ARMSTRONG	4299	4187			
ARNION	4367				
ASAT	4307	4247	4301		
AST	4259	4160			
ASTRA	4318	4307	4242	4247	4174
	4214	4130			
ASTRO	4157	4219	4253	4213	4372
	4314				
ASTRO SOUND	4314				
AVALON	4309				
AXIS	4339	4226	4275	4134	4197
	4306				
BELL EXPRESSVU	4453	4458			
BEST	4306	4275			
BLAUPUNKT	4157	4213	4372		
BOCA	4317	4299	4187	4131	4193
	4335				
BRITISH SKY BROADCASTING	4419	4390			
BROADBAND	4292	4293			
BT	4327	4143	4172	4138	
CAMBRIDGE	4172				
CANAL +	4155	4114			
CANAL DIGITAL	4155	4114			
CANAL SAT PILOTIME	4374				
CANAL SATELLITE	4374	4155	4114		
CHAPARRAL	4470	4430			
CITY COM	4308	4354	4337	4320	4140
CLEMENS KAMPHUS	4283				
COMMLINK	4302	4145	4153		
CONNEXIONS	4309				
CONRAD	4320	4140			
CONTEC	4226				
COOLSAT	4466				
CROSSDIGITAL	4456				
CROWN	4299	4187			
CYRUS	4147	4163			
DAEWOO	4366	4307	4247	4301	
D-BOX	4343	4351	4330		
DIGIQUEST	4367				
DIRECTV	4459	4450	4451	4448	4463
	4457	4449	4452	4464	4468
	4455	4456			
DIRECTV	4476	4477	4460	4461	4478
	4479				
DISH NETWORK SYSTEM	4453	4462	4458	4465	
DISHPRO	4453	4462	4465		
DISTRATEL	4345				
DMT	4348				
DNT	4309	4147	4163		
ECHOSTAR	4453	4462	4458	4465	4297
	4321	4342	4309	4328	4282
	4155	4297			
ECHOSTAR	4114				
EIF	4116				
EMANON	4311	4167			
EMME ESSE	4283				
EURODEC	4120				
EUTRA	4336	4283	4319		
EXPRESSVU	4453	4465			
FERGUSON	4182				
FIDELITY	4158	4133			
FINLUX	4313	4310	4242	4214	
FRACARRO	4342				
FREECOM	4311	4331	4167	4119	

FTE	4341	4305	4169	4220	4354
	4386	4132	4420		
FUBA	4306	4309	4311	4275	4116
	4167				
GALAXIS	4302	4341	4325	4339	4145
	4226	4185	4194	4197	4169
	4354				
GALAXISAT	4283	4259			
GARDINER	4337				
GBSAT	4357				
GE	4451	4432			
GENERAL INSTRUMENT	4454	4443			
GOI	4453	4465			
GOLDBOX	4155	4114			
GOODING	4135				
GRUNDIG	4135	4157	4191	4138	4390
	4213	4372			
HARTING UND HELLING	4221				
HARTING&HELLING	4283				
HAUPPAUGE	4424				
HIRSCHMANN	4315	4314	4336	4309	4310
	4283	4157	4301	4221	4136
	4253	4207			
HIRSCHMANN	4213	4372	4319	4350	4412
HITACHI	4473	4005	4440	4313	
HOUSTON	4327	4138	4295	4337	
HTS	4453	4465			
HUGHES NETWORK SYSTEMS		4457	4452	4464	4460
	4461	4004	4437	4447	
HUMAX	4475	4354	4341	4169	4386
	4420	4132			
HUTH	4299	4335	4302	4283	4145
	4187	4153	4128	4193	
HYUNDAI	4444				
INTERVISION	4185	4212	4325		
INVIDEO	4342				

ITT	4242	4214			
JOK	4138	4295	4337	4143	
JVC	4453	4458	4465	4172	4135
KAMM	4367				
KATHREIN	4312	4322	4308	4316	4326
	4305	4295	4218	4138	4147
	4219	4243			
KATHREIN	4170	4115	4220	4163	4186
KEY WEST	4335	4193			
KONGQUE	4367				
KOSMOS	4283	4305	4220		
KREISELMEYER	4157	4213	4372		
KYOSTAR	4311	4167			
LA SAT	4320	4317	4131	4140	
LABGEAR	4366				
LENCO	4311	4307	4247	4167	4301
LENNOX	4185	4212	4325		
LG	4477				
LORENZEN	4365				
LUPUS	4306	4275			
LUXOR	4242	4214			
MACAB	4198	4221	4204	4356	
MAGNAVOX	4436	4435			
MANHATTAN	4313	4349	4185	4361	
MARANTZ	4147	4163			
MASPRO	4218	4191	4136		
MATSUI	4135				
MEDIAMARKT	4299	4187			
MEDIASAT	4155	4114			
MEETRONIC	4328				
MEMOREX	4436				
MEMPHIS	4226				
MICRO TECHNOLOGY	4318	4221	4130		
MINERVA	4135				
MITSUBISHI	4452				
MITSUBISHI/MGA	4437				

MORGANS	4317	4299	4335	4187	4131
	4193				
MOTOROLA	4454	4443			
MULTICHOICE	4324	4376	4394		
MULTISTAR	4305	4220			
MYRYAD	4147	4163			
NETGEM	4370				
NEUHAUS	4314	4145	4253	4153	
NEUSAT	4339	4145	4197	4302	
NEXT LEVEL	4454	4443			
NEXT WAVE	4137				
NIKKO	4328				
NOKIA	4333	4351	4313	4427	4310
	4330	4343	4426	4429	4242
	4333	4214			
NORDMENDE	4253	4314			
NTC	4283				
OKANO	4283				
OLYMPIC	4283				
OPTIMA	4283				
ORBITECH	4314	4416	4389		
OTHERS	4289	4290	4291	4284	4288
	4420	4421	4422	4423	4428
PACE	4313	4329	4334	4419	4135
PALLADIUM	4253	4314			
PALSAT	4314				
PANASONIC	4449	4471	4476	4425	4003
	4021	4431	4434	4457	4390
PANDA	4313				
PANSAT	4467				
PATRIOT	4172				
PAYSAT	4436				
PHILIPS	4457	4452	4464	4455	4460
	4020	4437	4436	4445	4435
	4447	4346			
PHILIPS	4313	4416	4389	4147	4155
	4135	4138	4191	4143	4350
	4163	4114			
PHILIPS	4295	4337	4149	4294	4402
PHOENIX	4226				
PHONOTREND	4302	4319	4283	4145	4212
	4192	4281	4325		
PIONEER	4304	4155	4114		
PIXX	4319				
POLYTRON	4308				
PREISNER	4317				
PREMIER	4283				
PREMIERE	4351	4330	4343		
PROMAX	4313				
PROSAT	4302	4145	4153		
PROSCAN	4450	4451	4432		
PTT TELECOM	4329	4334	4139	4390	4126
	4146				
QUADRAL	4323	4184			
RADIOLA	4147				
RADIOSHACK	4454	4443			
RADIX	4309	4207	4350	4412	
RCA	4451	4469			
RCA/PROSCAN	4002	4007	4441	4432	4446
REBOX	4357				
REPLAY	4022				
RFT	4302	4176	4147	4145	4153
	4163				
RISKR	4287				
SABA	4331	4345	4125	4138	4119
SABRE	4313				
SAGEM	4338	4351	4196		
SAKURA	4226				
SALORA	4242	4214			
SAMSUNG	4459	4474	4456	4460	4478
	4479	4286	4301		
SAT	4259	4160	4133		

SATCOM	4180				
SATPARTNER	4283	4315	4311	4331	4156
	4167	4145	4119	4319	4336
SATSTATION	4349	4361			
SCHNEIDER	4138				
SCHWAIGER	4319	4316	4308	4115	
SEEMANN	4309	4134			
SEG	4318	4311	4332	4306	4275
	4167	4174	4190	4306	4130
SIEMENS	4157	4213	4372		
SKY	4419	4340	4442		
SKYMASTER	4283	4323	4328	4344	4302
	4145	4180	4184	4200	4153
SKYTV	4342				
SM ELECTRONIC	4296	4328			
SONY	4448	4463	4001	4017	4018
	4019	4074	4313	4433	4188
	4390				
STAR CHOICE	4454	4443			
STRONG	4186	4243	4312		
STVI	4116				
SUNSTAR	4317	4335	4193	4131	
TANTEC	4313				
TECHNISAT	4314	4154	4253	4176	
TECO	4307	4247	4301		
TELEFUNKEN	4311	4167			
TELEKA	4336	4299	4187	4181	4283
	4315				
TELESAT	4180				
TELESTAR	4296	4314			
TELEVES	4367				
THOMSON	4313	4347	4155	4114	
TIVO	4457	4460	4461		
TONNA	4327	4143	4295	4337	
TOPAY	4285				
TOSHIBA	4452	4464	4472	4006	4437
	4439	4447			
TPS	4338	4196	4397		
TRIAD	4259	4221	4160		
TRIASAT	4314	4253			
TRIAX	4314				
TWINNER	4116				
ULTRASAT	4466				
UNIDEN	4436	4435			
UNISAT	4226				
UNIVERSUM	4157	4135	4213	4372	
VECTOR	4221	4174			
VENTANA	4147	4163			
VOOM	4454				
VORTEC	4311	4167			
VTECH	4160	4125			
WEVASAT	4221				
WISI	4313	4309	4157	4259	4160
	4261	4159	4125	4213	4372
XCOM MULTIMEDIA	4128				
XSAT	4295	4143	4128	4138	4337
XTREME	4367				
ZEHNDER	4337	4305	4319	4348	4259
	4192	4220	4281		
ZENITH	4468	4442	4340		
ZODIAC	4309				
ZWERGNASE	4335	4193			

DVR Combos

BELL EXPRESSVU	4453	4458			
DIRECTV	4459	4450	4448	4457	4455
	4460	4461			
DISH NETWORK SYSTEM	4453	4462			
DISHPRO	4453	4462			
ECHOSTAR	4453	4462	4458	4297	4321
	4342	4309	4328	4282	4155

	4297	4114			
EXPRESSVU	4453				
HUGHES NETWORK SYSTEMS		4457	4460	4461	4004
	4437	4447			
JVC	4458	4172	4135		
MOTOROLA	4454	4443			
PHILIPS	4457	4460	4020	4437	4436
	4445	4435	4447	4346	4313
	4416	4389			
PHILIPS	4147	4155	4135	4138	4191
	4143	4350	4163	4114	4295
	4337	4149			
PHILIPS	4294	4402			
PROSCAN	4450	4432			
SAMSUNG	4460	4286	4301		
SONY	4448	4001	4017	4018	4019
	4074	4313	4433	4188	4390
STAR CHICE	4454				
TIVO	4457	4460	4461		

Brookstone®
A WORLD OF INNOVATION
Since 1965, people have come to Brookstone to see what's new, discover smart solutions to everyday problems—and have some fun. At Brookstone, we believe there's always a better way to do things. And we created a world of innovation to prove it.

650598 Code List

Merrimack, New Hampshire USA 03054 • 800-846-3000 • www.Brookstone.com